



# FMT100 User Manual

## V0.06

## Table of contents

<b>1</b>	<b>INTRODUCTION .....</b>	<b>7</b>
1.1	ATTENTION.....	7
1.2	INSTRUCTIONS OF SAFETY .....	7
1.3	LEGAL NOTICE.....	8
1.4	ABOUT DOCUMENT .....	8
<b>2</b>	<b>BASIC DESCRIPTION.....</b>	<b>8</b>
2.1	BASIC CHARACTERISTICS .....	8
2.2	TECHNICAL FEATURES .....	10
2.3	TECHNICAL INFORMATION ABOUT INTERNAL BATTERY .....	10
2.4	ELECTRICAL CHARACTERISTICS .....	11
2.5	ABSOLUTE MAXIMUM RATINGS.....	11
<b>3</b>	<b>CONNECTION, PINOUT, ACCESSORIES .....</b>	<b>12</b>
3.1	HOW TO INSERT MICRO SIM CARD INTO FMT100 DEVICE:.....	12
3.2	INSTALLING FMT100 DRIVERS .....	13
3.3	PINOUT .....	14
3.4	NAVIGATE LED .....	14
3.5	STATUS LED .....	14
<b>4</b>	<b>OPERATIONAL BASICS .....</b>	<b>15</b>
4.1	OPERATIONAL PRINCIPALS .....	15
4.2	SLEEP MODE .....	15
4.2.1	<i>Sleep mode</i> .....	15
4.2.2	<i>Deep Sleep mode</i> .....	15
4.2.3	<i>Online Deep Sleep mode</i> .....	16
4.2.4	<i>Ultra Sleep mode</i> .....	16
4.3	VIRTUAL ODOMETER .....	16
4.4	FEATURES .....	17
4.4.1	<i>Green Driving</i> .....	17
4.4.2	<i>Over Speeding</i> .....	18
4.4.3	<i>Excessive Idling</i> .....	18
4.4.4	<i>Jamming Detection</i> .....	18
4.4.5	<i>Trip</i> .....	18
4.5	ACCELEROMETER SCENARIOS.....	18
4.5.1	<i>Towing Detection</i> .....	18
4.5.2	<i>Unplug Detection</i> .....	18
4.5.3	<i>Crash Detection</i> .....	19
4.5.3.1	<b>Crash Trace operation</b> .....	19
4.6	BLUE-TOOTH .....	19
4.7	TRACKING ON DEMAND .....	19
<b>5</b>	<b>CONFIGURATION.....</b>	<b>20</b>
5.1	STATUS WINDOW .....	22
5.2	SECURITY SETTINGS .....	22
5.3	SYSTEM SETTINGS .....	23
5.4	GPRS SETTINGS .....	25
5.5	DATA ACQUISITION SETTINGS.....	26
5.6	SMS \ CALL SETTINGS.....	29
5.7	GSM OPERATORS LIST .....	30
5.8	FEATURES SETTINGS .....	31
5.8.1	<i>Green Driving</i> .....	31
5.8.2	<i>Over Speeding</i> .....	33
5.8.3	<i>Jamming</i> .....	33

5.8.4	GNSS Fuel Counter.....	33
5.9	ACCELEROMETER FEATURES SETTINGS .....	33
5.9.1	Excessive Idling.....	34
5.9.2	Towing Detection .....	34
5.9.3	Crash Detection .....	35
5.9.4	Unplug Detection .....	36
5.10	AUTO GEOFENCE SETTINGS.....	37
5.11	MANUAL GEOFENCE SETTINGS .....	38
5.12	TRIP \ ODOMETER SETTINGS .....	38
5.13	BLUE-TOOTH SETTINGS .....	40
5.13.1	How to connect Blue-tooth Hands Free adapter to FMT100 device .....	41
5.13.2	Device's log using your mobile phone. ....	43
5.14	BLUE-TOOTH 4.0 SETTINGS.....	44
5.15	I/O & OBD II SETTINGS.....	44
5.16	OBD FUNCTIONALITY DESCRIPTION .....	46
5.16.1	Supported OBD protocols.....	46
5.16.2	General info.....	46
5.16.3	Initialization .....	46
5.16.4	Data.....	47
<b>6</b>	<b>SMS COMMAND LIST.....</b>	<b>47</b>
6.1	BASIC COMMANDS.....	47
6.1.1.1	getinfo .....	48
6.1.1.2	getver .....	48
6.1.1.3	getstatus.....	48
6.1.1.4	getgps .....	49
6.1.1.5	ggps .....	49
6.1.1.6	readio # .....	49
6.1.1.7	getparam .....	49
6.1.1.8	setparam .....	49
6.1.1.9	setdigout .....	50
6.1.1.10	countrecs.....	50
6.1.1.11	towingreact .....	50
6.1.1.12	faultcodes.....	50
6.1.1.13	obdinfo .....	51
6.1.1.14	btgetlist .....	51
6.1.1.15	cleardtc.....	51
6.2	SYSTEM PARAMETERS:.....	51
6.2.1.1	Movement Source (ID=100) .....	51
6.2.1.2	Records Saving/Sending Without TS (ID=107).....	51
6.2.1.3	Led Indication (ID=108) .....	51
6.2.1.4	GNSS Source (ID=109) .....	51
6.2.1.5	Battery Charge Mode (ID=110).....	52
6.2.1.6	Static Navigation (ID=106).....	52
6.2.1.7	Static Navigation Settings (ID=112) .....	52
6.2.1.8	Sleep Mode (ID=102).....	52
6.2.2	Sleep Timeout (ID=103).....	53
6.2.2.1	Ignition Settings (ID=101).....	53
6.2.2.2	High voltage level (ID=104).....	53
6.2.2.3	Low voltage level (ID=105) .....	53
6.2.2.4	Movement start delay (ID=19001) .....	53
6.2.2.5	Movement stop delay (ID=19002).....	53
6.2.2.6	Time Synchronization (ID=900) .....	54
6.2.2.7	NTP Resync (ID=901) .....	54
6.2.2.8	NTP Server 1 (ID=902) .....	54
6.2.2.9	NTP Server 2 (ID=903) .....	54
6.3	GPRS PARAMETERS .....	54
6.3.1.1	GPRS Context (ID=2000) .....	54
6.3.1.2	APN (ID=2001) .....	54
6.3.1.3	APN Username (ID=2002).....	55

6.3.1.4	APN Password (ID=2003).....	55
6.3.1.5	Domain (ID=2004) .....	55
6.3.1.6	Target Server Port (ID=2005).....	55
6.3.1.7	Protocol (ID=2006) .....	55
6.3.1.8	Backup Server Mode (ID=2010).....	55
6.3.1.9	Backup Server Domain (ID=2008).....	56
6.3.1.10	Backup Server Port (ID=2008) .....	56
6.3.1.11	Protocol (ID=2009) .....	56
6.3.1.12	Open Link Timeout (ID=1000).....	56
6.3.1.13	Response Timeout (ID=1001) .....	56
6.3.1.14	Sort By (ID=1002).....	57
6.3.1.15	FOTA WEB Settings: Status (ID=13003) .....	58
6.3.1.16	FOTA WEB Settings: Domain (ID=13000).....	58
6.3.1.17	FOTA WEB Settings: Port (ID=13001) .....	58
6.3.1.18	FOTA WEB Settings: Period (ID=13002).....	58
6.4	DATA ACQUISITION SETTINGS.....	59
6.4.1	<i>Home Network GSM operator code "On stop" parameters.....</i>	<i>59</i>
6.4.1.1	Min Period (ID=10000) .....	59
6.4.1.2	Min Saved Records (ID=10004) .....	59
6.4.1.3	Send Period (ID=10005).....	59
6.4.2	<i>Home Network GSM operator code "Moving" parameters.....</i>	<i>59</i>
6.4.2.1	Min Period (ID=10050) .....	59
6.4.2.2	Min Distance (ID=10051).....	59
6.4.2.3	Min Angle (ID=10052).....	60
6.4.2.4	Min Speed delta (ID=10053).....	60
6.4.2.5	Min Saved Records (ID=10054) .....	60
6.4.2.6	Send Period (ID=10055).....	60
6.4.3	<i>Roaming Network GSM operator code "On stops" parameters .....</i>	<i>60</i>
6.4.3.1	Min Period (ID=10100) .....	60
6.4.3.2	Min Saved Records (ID=10104) .....	61
6.4.3.3	Send Period (ID=10105).....	61
6.4.4	<i>Roaming Network GSM operator code "Moving" parameters .....</i>	<i>61</i>
6.4.4.1	Min Period (ID=10150) .....	61
6.4.4.2	Min Distance (ID=10151).....	61
6.4.4.3	Min Angle (ID=10152).....	61
6.4.4.4	Min Speed (ID=10153).....	62
6.4.4.5	Min Saved Records (ID=10154) .....	62
6.4.4.6	Send Period (ID=10155).....	62
6.4.5	<i>Unknown Network GSM operator code "On stop" parameters .....</i>	<i>62</i>
6.4.5.1	Min Period (ID=10200) .....	62
6.4.5.2	Min Saved Records (ID=10204) .....	62
6.4.5.3	Send Period (ID=10205).....	62
6.4.6	<i>Unknown Network GSM operator code "Moving" parameters .....</i>	<i>63</i>
6.4.6.1	Min Period (ID=10250) .....	63
6.4.6.2	Min Distance (ID=10251).....	63
6.4.6.3	Min Angle (ID=10252).....	63
6.4.6.4	Min Speed (ID=10253).....	63
6.4.6.5	Min Saved Records (ID=10254) .....	63
6.4.6.6	Send Period (ID=10255).....	64
6.5	SMS \ CALL SETTINGS PARAMETERS.....	64
6.5.1.1	Allow SMS Data Sending (ID=3000).....	64
6.5.1.2	Data Send Number (ID=3001).....	64
6.5.1.3	Login (ID=3003) .....	64
6.5.1.4	Password (ID=3004).....	64
6.5.1.5	SMS Event Time Zone (ID=3006) .....	64
6.5.1.6	Incoming Call Settings (ID=3005).....	65
6.5.1.7	Authorized phone numbers (ID=4000-4199).....	65
6.5.1.8	SMS Event Predefined Numbers (ID=6000-6009).....	65
6.6	GSM OPERATORS PARAMETERS .....	65
6.6.1.1	Roaming Operator List (ID=5000-5049).....	65
6.6.1.2	Operator Black List (ID=5500-5549) .....	65
6.7	FEATURES PARAMETERS .....	65

6.7.1	<i>Green Driving parameters</i> .....	65
6.7.1.1	Scenario Settings (ID=11000) .....	65
6.7.1.2	Max Acceleration (ID=11004) .....	66
6.7.1.3	Max Braking (ID=11005) .....	66
6.7.1.4	Max Cornering (ID=11006) .....	66
6.7.1.5	Source (ID=11007) .....	66
6.7.1.6	Green Driving Duration (ID=11008).....	66
6.7.1.7	SMS Text (ID=8034) .....	66
6.7.2	<i>Over Speeding parameters</i> .....	67
6.7.2.1	Scenario (ID=11100) .....	67
6.7.2.2	Max Speed (ID=11104) .....	67
6.7.2.3	SMS Text (ID=8032) .....	67
6.8	JAMMING PAAMETERS .....	67
6.8.1.1	Scenario Settings (ID=11300) .....	67
6.8.1.2	Eventual Records (ID=11303) .....	67
6.8.1.3	Time Until Jamming Event Detection (ID=11305).....	67
6.8.2	<i>GNSS Fuel Counter settings</i> .....	68
6.8.2.1	City Consumption (L/100km) (ID=11900).....	68
6.8.2.2	Highway Consumption (L/100km) (ID=11901) .....	68
6.8.2.3	Average Consumption (L/100km) (ID=11902) .....	68
6.8.2.4	City Speed (km/h) (ID=11903) .....	68
6.8.2.5	Highway Speed (km/h) (ID=11904).....	68
6.8.2.6	Average Speed (km/h) (ID=11905) .....	68
6.8.2.7	Correction Coefficient (ID=11906).....	68
6.8.2.8	Fuel Consumption On Idling (L/h) (ID=11907) .....	69
6.8.2.9	Higher Speeds Add (%) (ID=11908).....	69
6.8.2.10	Highway Consumption Every (km/h) (ID=11909) .....	69
6.9	ACCELEROMETER FEATURES SETTINGS.....	69
6.9.1	<i>Excessive Idling settings</i> .....	69
6.9.1.1	Scenario Settings (ID=11200) .....	69
6.9.1.2	Eventual Records (ID=11203) .....	69
6.9.1.3	Time To Stopped (s) (ID=11205) .....	69
6.9.1.4	Time To Moving (s) (ID=11206) .....	69
6.9.1.5	SMS Text (ID=8033) .....	70
6.9.2	<i>Unplug Detection settings</i> .....	70
6.9.2.1	Scenario Settings (ID=11500) .....	70
6.9.2.2	Eventual Records (ID=11501) .....	70
6.9.2.3	Unplug Detection Mode (ID=11502) .....	70
6.9.2.4	Send SMS To (ID=7067) .....	70
6.9.2.5	SMS Text (ID=8036) .....	70
6.9.3	<i>Towing Detection</i> .....	71
6.9.3.1	Scenario Settings (ID=11600) .....	71
6.9.3.2	Eventual Records (ID=11601) .....	71
6.9.3.3	Activation Timeout (min) (ID=11602) .....	71
6.9.3.4	Event Timeout (s) (ID=11603).....	71
6.9.3.5	Threshold (g) (ID=11605).....	71
6.9.3.6	Angle (deg) (ID=11606).....	71
6.9.3.7	Duration (ms) (ID=11607).....	71
6.9.3.8	SMS Text (ID=8035) .....	72
6.9.4	<i>Crash Detection</i> .....	72
6.9.4.1	Scenario Settings (ID=11400) .....	72
6.9.4.2	Duration (ms) (ID=11401).....	72
6.9.4.3	Threshold (mg) (ID=11402).....	72
6.9.4.4	Crash Trace (ID=11406) .....	72
6.9.4.5	SMS Text (ID=8037) .....	72
6.10	AUTO GEOFENCE SETTINGS.....	73
6.10.1.1	Scenario Settings (ID=20000) .....	73
6.10.1.2	Eventual Records (ID=20002) .....	73
6.10.1.3	Generate Event (ID=20001) .....	73
6.10.1.4	Activation Timeout (ID=20003) .....	73
6.10.1.5	Radius (ID=20004) .....	73
6.10.1.6	SMS Text (ID=8030) .....	73

6.11	TRIP \ ODOMETER .....	74
6.11.1.1	Scenario Settings (ID=11800) .....	74
6.11.1.2	Eventual Records (ID=11801) .....	74
6.11.1.3	Mode (ID=11802) .....	74
6.11.1.4	Start Speed (km/h) (ID=11803).....	74
6.11.1.5	Ignition OFF Timeout (s) (ID=11804) .....	74
6.11.1.6	SMS Text (ID=8031) .....	74
6.11.1.7	Eco Score Allowed Events (ID=11804) .....	75
6.11.1.8	Calculation Source (ID=11806) .....	75
6.11.1.9	Odometer value (km) (ID=11807).....	75
6.12	BLUE-TOOTH SETTINGS .....	75
6.12.1.1	BT Radio (ID=800).....	75
6.12.1.2	Local Name (ID 801) .....	75
6.12.1.3	Local PIN (ID=802) .....	75
6.12.1.4	Security Mode (ID=803).....	76
6.12.1.5	Connection Mode (ID=807) .....	76
6.12.1.6	External MAC (ID=804) .....	76
6.12.1.7	External Name (ID=805) .....	76
6.12.1.8	External PIN (ID=806) .....	76
6.12.1.9	Authorized Devices MAC List (ID=830-834).....	76
6.13	I/O PARAMETERS.....	76
6.13.1.1	I/O#1 property parameter Ignition (ID=50000).....	77
6.13.1.2	I/O#1 Logic operand (ID=50001) .....	77
6.13.1.3	I/O#1 High level (ID=50002) .....	77
6.13.1.4	I/O#1 Low level (ID=50003) .....	77
6.13.1.5	I/O#1 Event only (ID=50004) .....	78
6.13.1.6	I/O#1 averaging length (ID=50005) .....	78
6.13.2	<i>I\O elements parameters and types</i> .....	78
6.14	OBD SETTINGS.....	83
6.14.1	<i>OBD elements parameters and types</i> .....	83
<b>7</b>	<b>EC DECLARATION OF CONFORMITY .....</b>	<b>88</b>
	<b>CHANGE LOG .....</b>	<b>89</b>

## 1 INTRODUCTION

### 1.1 Attention



Do not disassemble the device. If the device is damaged, before unplugging the power supply, do not touch the device.



All wireless data transferring devices produce interference that may affect other devices which are placed nearby.



Please consult representatives of your vehicle model regarding OBD II location on your vehicle. In case you are not sure of proper connection, please consult qualified personnel.



The programming must be performed using a second class PC (with autonomic power supply).



The device is susceptible to water and humidity.



Any installation and/or handling during a lightning storm are prohibited.



FMT100 has USB interface; Teltonika is not responsible for any harm caused by using wrong cables for PC <-> FMT100 connection.



Warning! Do not use FMT100 device if it distracts driver or causes inconvenience due to OBD II placement. Device must not interfere with driver.

### 1.2 Instructions of safety

This chapter contains information on how to operate FMT100 safely. By following these requirements and recommendations, you will avoid any dangerous situations. You must read these instructions carefully and follow them strictly before operating the device!

The device uses a 10 V... 30 V DC power supply. The nominal voltage is 12 V DC. The allowed range of voltage is 10 V... 30 V DC.

To avoid mechanical damage, it is advised to transport the FMT100 device in an impact-proof package.

Before dismounting the device from the vehicle, ignition must be off.

### 1.3 Legal Notice

Copyright © 2018 Teltonika. All rights reserved. Reproduction, transfer, distribution or storage of part or all of the contents in this document in any form without the prior written permission of Teltonika is prohibited.

Other products and company names mentioned here may be trademarks or trade names of their respective owners.

The manufacturer reserves the right to make changes and/or improvements at any time in design, functionality, parameters and electrical characteristics without any prior notice and without incurring obligations.

### 1.4 About document

This document contains information about the architecture, possibilities, mechanical characteristics, and configuration of the FMT100 device.

Acronyms and terms used in document:

PC – Personal Computer;

GPS – Global Positioning System;

GPRS – General Packet Radio Service;

GNSS – Global Navigation Satellite System;

GSM – Global System for Mobile Communications;

SMS – Short Message Service;

AC/DC – Alternating Current/Direct Current;

I/O – Input/Output;

Record – AVL data stored in FMT100 memory. AVL data contains GNSS and I/O information;

AVL packet - data packet which is being sent to the server during data transmission.

## 2 BASIC DESCRIPTION

FMT100 is a tracking terminal with GNSS and GSM connectivity, which is able to collect device coordinates and transfer them via GSM network to server. This device is perfectly suitable for applications, which need location acquirement of remote objects. It is important to mention that FMT100 has two pin interface. FMT100 also has a USB port for device status log output and device configuration.

### Package contents<sup>1</sup>

The FMT100 device is supplied to the customer in a cardboard box containing all the equipment that is necessary for operation. The package contains:

Already implemented FMT100 device;

Top and bottom device cover parts;

Li-ion battery.

### 2.1 Basic characteristics

GSM / GPRS / GNSS features:

- Teltonika TM2500 multi-band module (GSM 850 / 900 / 1800 / 1900 MHz);

---

<sup>1</sup> Package content depends on Order Code, and can be customized based on customer needs.



- GPRS class 12;
- SMS (text, data);
- Integrated GNSS receiver;
- Up to -161 dBm GNSS receiver sensitivity.

Hardware features:

- Built-in movement sensor;
- Built-in Blue-tooth 4.0;
- Internal High Gain GNSS antenna;
- Internal High Gain GSM antenna;
- 170 mAh Li-ion rechargeable 3.7 V battery.

Interface features:

- Power supply: 10 ÷ 30 V;
- USB port;
- 2 LEDs indicating device status.

Special features:

- Fast position fix;
- High quality track even in high density urban canyon;
- Small case;
- High gain internal GNSS and GSM antennas;
- 2 LED status indication;
- Real-time tracking;
- Smart data acquisition based on:
  - Time;
  - Angle;
  - Distance;
  - Ignition or any other I/O event.
- Sending acquired data via GPRS;
- GPRS and SMS I/O events;
- Virtual odometer;
- Jamming detection;
- Configurable using Secured SMS Commands;
- Spy call;
- Overvoltage protection.

## 2.2 Technical features

Table 1 FMT100 specifications

Part name	Physical specification	Technical details
Navigation LED	LED	<b>Technical details</b> Power supply 10... 30 V DC 2 W Max Energy consumption <sup>1</sup> : GPRS: --- 55 mA r.m.s Max., Nominal: --- average 26 mA r.m.s, Deep Sleep: --- average 9 mA, GPS Sleep: --- average 11 mA, Online Deep Sleep: --- average 6 mA, Ultra Sleep: --- average 4.5 mA <sup>2</sup> Battery charge current: --- average 120 mA, Rated current: --- 250 mA, Operation temperature: -10 °C ... +55 °C Storage temperature: -40 °C ... +70 °C Storage relative humidity 5 ... 95 % (no condensation) Internal fuse: 3A, 125V Weight: 63 g.
Modem LED	LED	
USB	Mini USB socket	




Figure 1 FMT100 view & dimensions (tolerance  $\pm 2\text{mm}$ )

## 2.3 Technical Information about internal battery

Li-ion rechargeable battery, 3.7 V, 170 mAh.

<sup>1</sup> Energy consumption has been tested at 12 V voltage with no battery charging.

<sup>2</sup> When in Deep Sleep mode no data storing and sending is activated.

Battery Disposal instructions:



Battery should not be disposed of with general household waste. Bring damaged or worn-out batteries to your local recycling center or dispose them to battery recycle bin found in stores.

**Warranty: batteries are covered by 6 month warranty support.**

**Table 2 Battery specifications**

Internal back-up battery	Battery voltage V	Nominal capacity (mAh)	Power(Wh)	Charging temperature °C
Li-ion rechargeable battery	3.50~3.90	≥170	0.64 - 0.66	0 – 45

FMT100 internal battery is used for detecting external voltage disconnection.



**CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.**

**2.4 Electrical characteristics**


CHARACTERISTIC DESCRIPTION	VALUE			
	Min.	Typ.	Max.	Unit
<b>Supply Voltage:</b>				
Supply Voltage (Recommended Operating Conditions)	10		30	V

**2.5 Absolute Maximum Ratings**


CHARACTERISTIC DESCRIPTION	VALUE			
	Min.	Typ.	Max.	Unit
Supply Voltage (Absolute Maximum Ratings)	-30		30	V

### 3 CONNECTION, PINOUT, ACCESSORIES


#### 3.1 How to insert micro SIM card into FMT100 device:




① Unscrew the screws.




② Remove the cover.



③ Insert micro SIM card as shown (bottom slot).



④ Insert SD card as shown (top slot).



⑤ Attach the cover and put the screws back in.

### 3.2 Installing FMT100 drivers

**Software requirements:**

- Operating system 32-bit and 64-bit: Windows XP with SP3 or later, Windows Vista, Windows 7.
- MS .NET Framework V3.5 or later (<http://www.microsoft.com> or <http://avl1.teltonika.lt/downloads/tavl/Framework/dotnetfx35setupSP1.zip>).


**Drivers:**

Please download COM Port drivers from Teltonika website:

[http://avl1.teltonika.lt/downloads/FMB1/MS\\_USB\\_ComPort\\_Driver\\_exe\\_v1.1032.3.zip](http://avl1.teltonika.lt/downloads/FMB1/MS_USB_ComPort_Driver_exe_v1.1032.3.zip)


**Installing drivers:**

Extract and run MS\_USB\_ComPort\_Driver\_exe\_v1.1032.3. This driver is used to detect FMT100 device connected to the computer. Click 'Next' in driver installation window (figures below):



**Figure 2 Driver installation window**

This will launch device driver installation wizard. In the following window click 'Install' button:



**Figure 3 Driver installation window**

Setup will continue installing drivers and will display a window about successful process at the end. Click 'Finish' to complete setup:




Figure 4 Driver installation window

You have now installed drivers for FMT100 device successfully.

### 3.3 Pinout

Color	Pin Name	Description
Black	GND (-)	Ground pin
Red	Power +(10÷30) V DC	Power range +(10...30) V, DC to Ground

### 3.4 Navigate LED

Behavior	Meaning
Permanently switched on	GNSS signal is not received
Blinking every second	Normal mode, GNSS is working
Off	GNSS is turned off because: <ul style="list-style-type: none"> <li>• Deep sleep mode</li> </ul> Or <ul style="list-style-type: none"> <li>• GNSS antenna short circuited</li> </ul>

### 3.5 Status LED

Behavior	Meaning
Blinking every second	Normal mode
Blinking every 2 seconds	Deep sleep mode
Blinking fast for a short time	Modem activity
Blinking fast constantly	Boot mode
Off	<ul style="list-style-type: none"> <li>• Device is not working</li> </ul> Or <ul style="list-style-type: none"> <li>• Device firmware being flashed</li> </ul>

## 4 OPERATIONAL BASICS

### 4.1 Operational principals

FMT100 module is designed to acquire records and send them to the server. Records contain GNSS data and I/O information. Module uses GNSS receiver to acquire GNSS data and is powered with three data acquiring methods: time-based, distance-based and angle-based. Note, that if FMT100 loses connection to GNSS satellites, it continues to make records, however coordinate in these records remains the same (last known coordinate). All data is stored in flash memory and later can be sent via GPRS.

GPRS and SMS settings are described in later sections. FMT100 communicates with server using special data protocol.

FMT100 can be managed by SMS commands. SMS Command list is described in SMS COMMAND LIST section. Module configuration can be performed only via SMS.

### 4.2 Sleep mode

#### 4.2.1 Sleep mode

FMT100 is able to go to sleep mode if such mode is enabled.

This timeout (defined period) starts counting when device is in STOP mode. After timeout is reached and all conditions for sleep mode are met, device goes to sleep mode. While in sleep mode, FMT100 turns GPS module off and it is still making new periodic records. As a result power usage decreases, in turn saving vehicle battery.

FMT100 can enter sleep mode if **ALL** of these conditions are met:

- FMT100 has to be configured to work in Sleep mode and start sleep timeout is reached;
- Device must have synchronized time with GNSS satellites;
- No movement by movement sensor is detected;
- Ignition (configured Ignition Source) is off.

FMT100 exits sleep mode when if **ONE** of following conditions are true:

- Movement by movement sensor is detected;
- Ignition (configured Ignition Source) is turned on.

#### 4.2.2 Deep Sleep mode

While in deep sleep mode, FMT100 sets GNSS receiver to sleep mode and turns off GSM/GPRS module (it is not possible to wake up device via SMS). Despite records with last known coordinate are being saved and send to AVL server (GSM/GPRS module is turned on to send data and after that it is turned off again), power usage is decreased to save vehicle's battery. Note, that power saving depends on two configurable parameters: send period and min. record saving period in "X on Stop Mode".

FMT100 can enter deep sleep mode if **ALL** of these conditions are met:

- FMT100 has to be configured to work in Deep Sleep mode;
- Device must be synchronized time with GNSS satellites;
- FMT100 has to be in „X on Stop Mode“ (Configured by Mode switch parameter);

- Movement by accelerometer is not detected;
- Ignition (Configured to be detected by Power Voltage, Ignition or Accelerometer) is off;
- Min. Record Saving Period (Data Acquisition Mode settings) must be bigger than Active Data Link Timeout parameter, that FMT100 could close GPRS link.
  - Send period (Data Acquisition Mode settings) minus Active Data Link Timeout must be more than 90 sec., that FMT100 could close GPRS link for at least 90 sec.
  - Sleep timeout is reached.

FMT100 exits deep sleep mode when if **ONE** of following conditions are true:

- Movement by accelerometer is detected;
- Ignition (Configured to be detected by Power Voltage, Ignition or Accelerometer) is turned on.

#### **4.2.3 Online Deep Sleep mode**

In this mode device works as in Deep Sleep mode, but without turning off GSM network. GSM part stays powered, so this increases power consumption. In this mode, device should received/send SMS and make/receive calls. Also not closes GPRS context, if previously opened.

#### **4.2.4 Ultra Sleep mode**

In this mode device turns of all of the functionality. Both LEDs are also off.

### **4.3 Virtual Odometer**

Virtual Odometer is used to calculate distance travelled in FMT100 as a separate I/O element. When FMT100 detects movement, it starts counting distance using GNSS signal: every second it checks current location and calculates distance between current and previous point. It keeps adding these intervals until it is time to make a record, then FMT100 records its location and adds odometer value, which is equal to the sum of all distances, measured every second. User can choose Odometer mode: 0 – Normal mode, or 1 – Continuous.

At Normal mode, when record is made, odometer resets to zero and distance calculation starts all over again.

Continuous odometer mode requires ignition (configured Ignition source) to be turned on. Odometer counts all distance calculations from records and sums them to one distance. Continuous odometer stops counting, when vehicle is at stop and ignition is turned off.






Figure 5 Odometer continuous and normal (not continuous) distance counting parameter example

#### 4.4 Features

Using available features can greatly increase FMT100 usability options.

##### 4.4.1 Green Driving

Helps to prevent and inspect driver about harsh driving. Scenario continuously monitors: accelerating force, braking force and cornering angles.

To prevent generating false events, harsh acceleration and harsh braking is monitored only when following conditions are fulfilled:

- Ignition is ON;
- Vehicle speed is equal or higher than 10 km/h.

Harsh cornering is monitored only when following conditions are fulfilled:

- Ignition is ON;
- Vehicle speed is equal or higher than 30 km/h.

Some new parameters and IO elements are introduced with FMT100.

Table 3 Green Driving new parameters

Parameter ID	Parameter type	Default value	Value range		Parameter name
			Min	Max	
11009	Uint16	30	10	1000	Green driving start timeout
11010	Uint16	100	10	1000	Green driving stop timeout

Table 4 Eco Driving new parameters

IO element AVL ID	Element type	Element name
258	Uint64	Eco driving max value
259	Uint64	Eco driving average value
260	Uint16	Eco driving duration



Note: Green Driving Scenario is a factor on various cars and various drivers testing phase and can be subject to changes. Teltonika is constantly working on improvement of the functionality of the devices, and strongly recommends using the latest version of the firmware.

#### **4.4.2 Over Speeding**

Helps to prevent from exceeding fixed speed and inspects driver if needed.

#### **4.4.3 Excessive Idling**

Informs you if your vehicle is stationary but engine is on for selected period of time to help you to save fuel

#### **4.4.4 Jamming Detection**

Shows when GSM signal jamming occurs.

#### **4.4.5 Trip**

Enables user extended monitoring of performed trips (from engine start at present location to engine stop at arrived location), log their start and stop points, view driven total distance<sup>3</sup>. Event will be generated (included into send records) only when trip starts and finishes.

### **4.5 Accelerometer scenarios**

#### **4.5.1 Towing Detection**

Helps to inform driver about car moving with ignition off. FMT100 generates event when car is being towed or raised, for example in case of vehicle evacuation.

FMT100 activates towing function when these conditions are met:

- Ignition (configured Ignition Source) is OFF;
- Activation Timeout (set in Towing detection features) is reached.

When Activation Timeout is reached and Ignition is still in OFF state, FMT100 monitors accelerometer data. If Acceleration or Angle value reaches configured threshold for configured Duration (in milliseconds), check Ignition state. If Ignition is still OFF during configured "Ignition check after Event Timeout" time, then event is generated. If configured - sends SMS event or makes a call.

Function will be reactivated after FMT100 again detects change of Ignition state from ON to OFF.

#### **4.5.2 Unplug Detection**

Generates event when FMT100 is unplugged from external voltage source.

---

<sup>3</sup> Continuous odometer – total driven distance, works only in TRIP mode. Continues distance is counted only for ONE trip. If trip is finished (stop point is detected), odometer resets to 0 (zero). Next trip will start counting from the beginning.

### 4.5.3 Crash Detection

If Crash Detection is enabled, it monitors acceleration on each axis, if acceleration exceeds configured threshold for configured duration then crash event is generated. Depending on configuration crash record structure follows codec 8 or codec 8 extended protocol structure. If codec 8 extended enabled crash event records are sent without any IO elements, only GNSS and accelerometer data if it is in configured range.

#### 4.5.3.1 Crash Trace operation

If Crash Trace is enabled FMT100 will collect acceleration data every 40 milliseconds.

### 4.6 Blue-tooth

Blue-tooth can work in two modes - *slave* or *master*.

While working as *master* mode - Blue-tooth can connect to defined "*hands free*" or "*OBDII*" system.

While working as *slave* mode - Blue-tooth can accept incoming connection from external device.

### 4.7 Tracking on Demand

After device receives SMS/GPRS command " on\_demand\_trackingX" where X is [0:2] value, then device starts to generate high priority records and initiate data sending to server. This feature is configurable via SMS/GPRS commands only.

Some new Tracking on Demand parameters are introduced in FMT100.

**Table 5 Tracking on Demand parameters and values**

Parameter ID	Parameter type	Default value	Value range		Parameter name
			Min	Max	
10990	Uint8	10	5	60	Tracking period
10991	Uint16	600	300	3600	Tracking duration

**Table 6 Tracking on Demand SMS/GPRS commands**

SMS/GPRS command	X value, meaning
on_demand_trackingX	0 – Stops Tracking on Demand functionality
	1 – Starts Tracking on Demand functionality
	2 – Generates one high priority record and initiates data sending to server

## 5 CONFIGURATION

New FMT100 module has default factory settings. Settings should be changed according to your application and your GSM operator information.

It can be configured to acquire and send data to server. If device is not able to send data to server (e. g. GPRS connection is not available) FMT100 will start storing records to flash memory. It will send data later when GPRS is available again. Note that FMT100 can have memory full of records. In such case it will start deleting the oldest records in order to save new ones. Please be aware that sending all data records to server may take some time.

FMT100 configuration may be performed via SMS commands or Configurator application, which will be introduced in this chapter. Contact sales manager to get the latest FMT100 Configurator version.

FMT100 Configurator operates on Microsoft Windows OS and uses MS .Net Framework 3.5 or higher. Please ensure that MS .Net Framework 3.5 or later is installed on your PC before starting configurator. Latest MS .Net Framework version can be downloaded from official Microsoft web page.

Module configuration can be performed over USB cable or Blue-tooth connection. Configuration process starts from starting FMT100 Configurator program and then connecting to FMT100 device via Connect button located in the middle of home screen (see Figure 6). FMT100 has one user editable profile, which can be loaded from device, and saved. User can also revert to default settings, by pressing Reset to defaults button. After any modification of configuration settings, it has to be saved to FMT100 device, otherwise it will not be written to device.



Note: It is not recommended to downgrade firmware. We can't guarantee that all functions will be working correctly - it is possible that in old firmware versions there won't be some functions.



Figure 6 Configurator connection window

**Connection window buttons description:**

'Create new configuration' – opens offline configurator.

'Connect to device' (on the right, with connected device info) – connects to the device.



**Figure 7 Configurator control bar**

**Control bar buttons description:**

'Load from device' – loads the configuration from device.

'Save to device' – saves the configuration to device.

'Load from file' – loads the configuration from external file.

'Save to file' – saves the configuration to external file.

'Update firmware' – updates device firmware version.

'Read records' – reads records from external file.

'Reset device' – resets device.

'Disconnect from device' (with device info) – disconnects from device.

As it was mentioned, device may also be configured via SMS (GPRS) commands.

**Keyword SMS (GPRS) commands:**

"setkey <oldkeyword> <newkeyword>" - Set new or change the keyword. Configuration should be not locked. Example:

**New keyword (set):**

<name>{space}<pass>{space}setkey{space}{space}{space}<newkeyword>

**Change keyword (change):**

<name>{space}<pass>{space}setkey{space}<oldkeyword>{space}<newkeyword>

"delkey <keyword>" - Deletes current keyword. Configuration keyword should be configured and not locked.

**Example:**

<name>{space}<pass>{space}setkey{space}<keyword>

## 5.1 Status window

The Status window displays the following information:

- Device Info:**
  - Device Name: FMT100
  - Last Start Time: 1/1/2004 2:00:12 AM
  - Power Voltage: 12778 mV.
  - Ext Storage (used/total): 1 / 122 MB
  - Battery Voltage: 0 mV.
  - Firmware Version: 03.16.03 Rev:00
  - RTC Time: 1/1/2004 2:02:27 AM
  - Device IMEI: [REDACTED]
  - Device Uptime: 00:02:15
  - Internal Battery Status: Not Charging 0%
- GNSS Info:**
  - GNSS Status:**
    - Module Status: ON
    - GNSS Packets: 120
    - Fix Status: No fix
    - Fix Time: 00:00:00
  - Satellites:**
    - GPS: 0
    - BeiDou: 0
    - GLONASS: 0
    - Galileo: 0
    - Total Satellites: 0
    - Satellites In Use: 0
  - Location:**
    - Latitude/Longitude: 0\_0
    - Altitude: 0
    - HDOP: 0
    - Speed: 0 km/h
    - Angle: 0°
    - PDOP: 0

Figure 8 Status window

Status window shows main information about the connected device. It can be divided into five main parts:

1. Device Info – shows general information about connected device e. g. Device Name, Device IMEI, etc.
2. GNSS Info tab – shows GNSS information such as Modem Status, connected GNSS satellite types, current coordinates, etc.
3. GSM Info – shows main information regarding GSM such as SIM State, GPRS Status and so on.
4. I/O Info – shows information about the current status of various inputs and outputs.
5. Maintenance – enables to receive current log file.

## 5.2 Security settings

The Security settings window displays the following information:

- Sim 1:**
  - SIM State: Active
  - SIM Status: Initializing
  - Attempts Left: 3
- Keyword Settings:**
  - Set keyword
  - New Keyword:
  - Repeat Keyword:
  - Set

Figure 9 Security settings window

The purpose of Security settings is to enable the user to set a keyword, which serves as a protection, required if device will be connected to the Configurator again.

### 5.3 System settings

System settings configurable parameters:

1. Sleep settings, where user can choose sleep mode;
2. Ignition source, where user can choose between power voltage, digital input 1 and accelerometer ignition sources
3. Object Motion Detection Settings, where user can configure 3 ways how FMT100 will detect stopped movement, and change its working mode;
4. Static navigation settings, where user can turn static navigation on or off;
5. Records Settings, where user can enable or disable records when GPS is not available (no time synchronization);
6. GNSS source Settings, where user can choose satellite system.
7. LED indication, where user can turn on or off indication LEDs.
8. Data protocol – standard Codec8 or new Codec8E (extended).
9. Battery charge mode, where user can choose when battery charger is turned on. Battery charge mode “On Need” - Enable battery charger any time when needed. “After Ignition ON” - Charger can be enabled after ignition is turned on, except if battery is fully charged or 10 minute timeout has not passed since device was turned on for faster FIX receiving.  
Crash
10. Time synchronization mode, where you can choose how time synchronization is done.  
Possible values:
  - a) Disable (GPS only) – time is synchronized only from GNSS satellites
  - b) NITZ – time is synchronized from GNSS satellites or GSM operator (not all GSM operators support this functionality)
  - c) NTP – time is synchronized from GNSS satellites or NTP servers.
  - d) NITZ+NTP – time can be synchronized from GNSS satellites, GSM operator or NTP server





Figure 10 Time Synchronization settings

If necessary, you can configure your NTP servers and how often device should resynchronize time from NTP (NTP Resync parameter).

**Table 7 Configuration parameters**

Movement Source	Vehicle on Stop mode	Vehicle Moving mode
Ignition (recommended)	If ignition (DIN1) is logic low	If ignition (DIN1) is logic high
Movement (movement sensor)	Internal movement sensor does not detect movement	Internal movement sensor detects movement
GPS	GPS fix is available and vehicle speed is lower than 5 km/h	GPS fix is available and vehicle speed is higher than 5 km/h
	While GPS fix is unavailable, Object Motion Detection Settings are working like in Msensor mode	
CAN Speed	Car CAN line does not produce a sufficient Speed value	Car CAN line produces a sufficient Speed value

Static Navigation Mode is a filter, which filters out track jumps when the object is stationary. If Static navigation filter is disabled, it will apply no changes on GPS data. If Static navigation filter is enabled, it will filter changes in GPS position if no movement is detected (depends on Object Motion Detection Settings). It allows filtering GPS jumps when object is parked (is not moving) and GPS position is still traced.



**Figure 11 System settings configuration**

In GNSS source Settings user can configure which GNSS system or systems to use.

User has choice to use only one system of GPS, GLONASS, Galileo or BeiDou. Also it is able to choose two or three systems together. One exception is that you can not combine BeiDou and GLONASS systems together.

List of configurable GNSS sources:

BeiDou only	ID:01	GNSS Source	
GLONASS only	ID:02	BeiDou	GLONASS
		Galileo	GPS



Galileo only	ID:04
Galileo + BeiDou	ID:05
Galileo + GLONASS	ID:06
GPS only	ID:08
GPS + BeiDou	ID:09
GPS + GLONASS	ID:10
GPS + Galileo	ID:12
GPS + Galileo + BeiDou	ID:13
GPS + Galileo + GLONASS	ID:14

Example of a good configuration

List of **NON**-configurable GNSS sources:

- GLONASS +BeiDou
- Galileo + GLONASS + BeiDou
- GPS + GLONASS + BeiDou
- GPS + Galileo + GLONASS + BeiDou

BeiDou	GLONASS
Galileo	GPS

Example of a bad configuration

#### 5.4 GPRS settings

'GPRS' defines main parameters for FMT100: GSM operator APN and GPRS username and password (optional – depending on operator), destination server IP and port, and allows to set protocol used for data transfers – TCP or UDP.

Some operators use specific authentication for GPRS session – CHAP or PAP. If any of these is used, APN should be entered as 'chap:<APN>' or 'pap:<APN>'. I.e. if operator is using APN 'internet' with CHAP authentication, it should be entered as 'chap:internet'. Information about APN and authentication type should be provided by your GSM operator.

Backup Server settings enables the user to activate a backup server if Backup mode is selected and a parallel server if Duplicate option is selected.

Open Link Timeout is used to set timeout of link between FMT100 and AVL application termination. If FMT100 has already sent all records it waits for new records before closing link. If new records are generated in the period of this timeout, and minimum count to send is reached, they are sent to AVL application. This option is useful when GSM operator charge for link activation.

Server Response Timeout is used to set time period waiting for response from server side.

Also, here user can modify if FMT100 device will send newest records first, meaning, that the most important thing is to know recent position of car, older records are being sent right after newest records arrive to AVL application.

Status	<b>GPRS Settings</b>		<b>Records Settings</b>	
Security	GPRS Context Disable <input type="radio"/> Enable <input checked="" type="radio"/>		Open Link Timeout (s) <input type="text" value="30"/>	
System	APN <input type="text" value="banga"/>	Response Timeout (s) <input type="text" value="30"/>		Network Ping Timeout(s) <input type="text" value="0"/>
<b>GPRS</b>	APN Username <input type="text"/>	Sort By Newest <input checked="" type="radio"/> Oldest <input type="radio"/>		
Data Acquisition	APN Password <input type="text"/>	<b>FOTA WEB Settings</b>		
SMS \ Call Settings	Normal(PAP) <input checked="" type="radio"/> Secured(CHAP) <input type="radio"/>		Status Disable <input type="radio"/> Enable <input checked="" type="radio"/>	
GSM Operators	<b>Server Settings</b>		Domain <input type="text" value="fm.teltonika.it"/>	
Features	Domain <input type="text" value="212.59.13.226"/>	Port <input type="text" value="24000"/>		Port <input type="text" value="5000"/>
Accelerometer Features	Port <input type="text" value="24000"/>	Protocol TCP <input checked="" type="radio"/> UDP <input type="radio"/>		Period (min) <input type="text" value="720"/>
Auto Geofence	Protocol <input type="text" value="TCP"/>	<b>Backup Server Settings</b>		
Manual Geofence	Backup Server Mode Disable <input type="radio"/> Backup <input checked="" type="radio"/>			
Trip \ Odometer	Duplicate <input checked="" type="radio"/>			
Blue-tooth	Backup Server Domain <input type="text"/>			
Blue-tooth 4.0	Backup Server Port <input type="text" value="0"/>			
I/O	Backup Server Protocol TCP <input checked="" type="radio"/> UDP <input type="radio"/>			
OBD II				

Figure 12 GPRS settings window

## 5.5 Data Acquisition settings

Data Acquisition Modes are an essential part of FMT100 device, it is also highly configurable.

By configuration user defines how records will be saved and sent. There are three different modes: Home, Roaming and Unknown. All these modes with configured data acquisition and send frequencies depend on current GSM Operator defined in Operator list (see section 0) and are switched when GSM operator changes (e.g. vehicle passes through country boarder).

If current GSM operator is defined as Home Operator, device will work in Home Data Acquisition mode, if current operator is defined as Roaming Operator, device will work in Roaming Data Acquisition mode, and if current operator code is not written in Operator list (but there is at least one operator code in the operator list), device will work in Unknown Acquisition mode.

This functionality allows having different AVL records acquire and send parameters values when object is moving or stands still. Vehicle moving or stop state is defined by Stop Detection Source parameter. There are 3 ways for FMT100 to switch between Vehicle on Stop and Vehicle Moving modes see section 5.7.

FMT100 has 6 different modes. Operational logic is shown in Figure 14.



If there are no operator codes entered into operator list, FMT100 will work in Unknown network mode ONLY.




Figure 13 Data Acquisition Mode configuration

Operator search is performed every 15 minutes. Depending on current GSM operator, Home, Roaming or Unknown mode can be changed faster than every 15 minutes. This process is separate from operator search. Movement criteria are checked every second.

Status	<b>On stop</b>		
Security	Home	Roaming	Unknown
System	Min Period: 30	3600	3600
GPRS	Min Saved Records: 1	1	1
Data Acquisition	Send Period: 60	120	120
SMS \ Call Settings	<b>Moving</b>		
GSM Operators	Home	Roaming	Unknown
Features	Min Period: 10	300	300
Accelerometer Features	Min Distance: 100	100	100
Auto Geofence	Min Angle: 10	10	10
Manual Geofence	Min Speed Delta: 10	10	10
Trip \ Odometer	Min Saved Records: 1	1	1
Bluetooth	Send Period: 60	120	120

Figure 14 Data Acquisition Mode configuration


'Min Saved Records' defines minimum number of coordinates and I/O data that should be transferred with one connection to server. If FMT100 does not have enough coordinates to send to server, it will check again after time interval defined in "Sending Period".

Send period – GPRS data sending to server period. Module makes attempts to send collected data to server every defined period. If it does not have enough records (depends on parameter Min. Saved Records described above), it tries again after defined time interval.




Note: Keep in mind that FMT100 operates in **GMT: 0** time zone, without daylight saving.


FMT100 is able to collect records using four methods at the same time: time, distance, angle and speed based data acquisition:



Distance based data acquiring (Min. distance) – records are being acquired when the distance between previous coordinate and current position is greater than defined parameter value. Entering zero disables data acquisition depending on distance.



Angle based data acquiring (Min. angle) – records are being acquired when angle difference between last recorded coordinate and current position is greater than defined value. Entering zero disables data acquisition depending on angle.



Speed based data acquiring (Min. Speed Delta) – records are being acquired when speed difference between last recorded coordinate and current position is greater than defined value. Entering zero disables data acquisition depending on speed.



## 5.6 SMS \ Call Settings

Figure 14 SMS \ Call settings window

Essential fields in 'SMS' part are 'Login' and 'Password'. The login and password are used with every SMS sent to FMT100. If login and password are not set, in every SMS sent to FMT100 device two spaces before command have to be used (<space><space><command>).

Command structure with set login and password:

<login><space><password><space><command>, example: "asd 123 getgps"

Phone numbers have to be written in international standard, without using "+" or "00" signs in prefix. This applies for Authorized Numbers and GSM Predefined Numbers lists. Authorized Numbers List holds numbers of the devices which are given permission to use commands (if no numbers are set, any number can use SMS commands). If no numbers are entered, configuration and sending commands over SMS are allowed from all GSM numbers. GSM Predefined Numbers holds the numbers which will be able to receive SMS messages generated by the I/O system.

The sent SMS messages format is according to: "Date Time EventText"

For example, if FMT100 is configured to send an SMS, when Ignition reaches High level, with priority High and configured to generate event on both, range enter and exit, then the sent SMS is: "2012/6/7 12:00:00 Ignition 1".

Input Name	Current Value	Units	Priority	Low Level	High Level	Event Only	Operand	Avg Const	Send SM:
Ignition	1		None Low High Panic	0	0	Yes No	On Both	10	
Movement	1		None Low High Panic	0	0	Yes No	On Change	10	
Data Mode	5		None Low High Panic	0	0	Yes No	Monitoring		
GSM Signal	0		None Low High Panic	0	0	Yes No	Monitoring	1	
Sleep Mode	0		None Low High Panic	0	0	Yes No	Monitoring		
GNSS Status	2		None Low High Panic	0	0	Yes No	Monitoring		
GNSS PDOP	0		None Low High Panic	0	0	Yes No	Monitoring	10	
GNSS HDOP	0		None Low High Panic	0	0	Yes No	Monitoring	10	
External Voltage	12776	mV	None Low High Panic	0	0	Yes No	Monitoring	10	
Speed	0	km/h	None Low High Panic	0	0	Yes No	Monitoring	1	
GSM Cell ID	0		None Low High Panic	0	0	Yes No	Monitoring		
GSM Area Code	0		None Low High Panic	0	0	Yes No	Monitoring		
Battery Voltage	0		None Low High Panic	0	0	Yes No	Monitoring	10	

Figure 15 Configured Ignition SMS event

SMS data sending settings – enable or disable periodic data and event SMS usage. This setting does not affect replies to SMS request messages – answers are always sent back to sender telephone number.

Incoming Call setting defines what device does, when it receives a call. It can hang-up or report its position.

FMT100 works with synchronized GPS time which is UTC+0, with SMS Event Time Zone option customer can configure his time zone and get SMS with correct time.



Note: Please do not set Data Send Number to some cell phone number, because it will not understand binary SMS. When sending a binary SMS to a phone number, which is a server phone number, the server can interpret and understand binary code, so the data can be read and you can view it on the server.



SMS login and password and authorized number list are used to protect FMT100 module from unauthorized access. Module accepts messages only from a list of authorized numbers and with proper module login and password. Numbers must be without “+” or “00” prefix. If no authorized numbers are entered, module accepts messages from all numbers.

The SMS Text field can be altered and any text can be entered. Maximum message length is 90 symbols (numbers, letters and symbols in ASCII, except for comma “,”).



#### ATTENTION!

If FMT100 is in Deep Sleep mode and SMS event occurs with LOW priority (which does not wake up FMT100), then the device does not send the message. It is saved in device memory until it wakes up from Deep Sleep mode and GSM modem starts working normally. After it wakes up, all the messages that are saved in memory will be sent, but keep in mind that only 10 messages can be saved in memory – all other messages will not be saved, until there is room in device memory.

## 5.7 GSM Operators list

Operators list – FMT100 can work in different modes (use different settings) according to the operator list defined. Operator list is used for Data Acquisition Mode switching Modes are changed based on GSM operator FMT100 is connected to.




Figure 16 Operator list configuration

If operator list is left empty, it will allow using GPRS to any GSM operator as Home operator. Please note that FMT100 will work in **Unknown mode only** unless data sending is allowed – GPRS context is enabled.

## 5.8 Features settings

In Features window four different scenarios are available.




Figure 17 Scenarios configuration

### 5.8.1 Green Driving

Scenario is activated, when vehicle exceeds set parameters. User can configure Max. Acceleration, Max. Braking and Max. Cornering parameters in m/s<sup>2</sup> units, also the source of data. Scenario is activated until current Acceleration, Braking or Cornering value decreases below parameter value.

Parameters used with Green Driving functionality.

**Green Driving**

Scenario Settings

Disable	Low Priority
High Priority	Panic Priority

Max Acceleration (m/s<sup>2</sup>)  ▲▼

Max Braking (m/s<sup>2</sup>)  ▲▼

Max Cornering (m/s<sup>2</sup>)  ▲▼

Figure 18 Green driving configuration parameters

Green Driving configuration parameter name	Description
Green Driving	Enable/Disable Green Driving functionality
Max Acceleration Force	Value which can be reached while accelerating without triggering harsh acceleration event.
Max Braking Force	Value which can be reached while braking without triggering harsh braking event.
Max Cornering Force	Value which can be reached while cornering without triggering harsh cornering event.

Green driving functionality generates events on three cases. If vehicles:

- Acceleration exceeds defined parameter value
- Deceleration (braking) exceeds defined value
- Cornering force exceeds defined value

Program continuously monitors and process data from accelerometer than decides whether harsh event is detected or not. If any of three cases are satisfied event is generated. Record is saved and sent to server (FMT100 must be configured properly). Event value is multiplied by 10 before sending/saving record to get more precision when displaying **data\***.

Digital output No.1 is activated for a period of time to warn driver. Output on-time should/can be configured separately for each case.

**\*Example.** If acceleration harsh event of 3.55 m/s<sup>2</sup> detected. Record with value 3.55\*10 = 35.5 ≈ 36 will be saved and sent to server.

#### Auto Calibration

1. Vehicle stopped
2. Road is straight
3. Send SMS "auto\_calibrate"
4. Accelerate to > 30 km/h for 5 sec.
5. FMT100 will send response when calibration is success.

Calibration is saved to Internal Flash, after restart should be the same



To check autocalibration status send: position\_info  
 To zero out accelerometer axis SMS: "calibrate", can be used, vehicle speed must be 0 km/h.

### 5.8.2 Over Speeding

Scenario is activated, when vehicle speed exceeds parameter value. Scenario is activated until current speed decreases below parameter value.

### 5.8.3 Jamming

Scenario is activated (event sent to server), when jamming is detected.

### 5.8.4 GNSS Fuel Counter

1. To configure these parameters use fuel consumption data, which is stated in your car technical documentation. By default speeds for this fuel consumption norms are: City – 30 km/h, Average – 60 km/h, Highway - 90 km/h. If you want, you can change it.

2. When speed is higher than highway speed, FMT100 adds highway fuel consumption x % of highway fuel consumption every y km/h, by default FMT100 adds 20% every 50 km/h. It means that fuel consumption is (1.2 \* Highway Fuel Consumption) on 140 km/h speed, (1.4 \* Highway Fuel Consumption) on 190 km/h speed.

3. Correction coefficient is used for correction of every fuel consumption value which is sent to server (Used Fuel \* Correction coefficient). By default it is 1, min 0.01 and max 2. For example when correction coefficient is 1 and FMT100 calculates that used fuel for 35 m distance is 20 ml, sent value will be 20 ml; if correction coefficient is 1.2, sent value will be 20 \* 1.2 = 24 ml.

GNSS Fuel Counter	
City Consumption (L/100km)	0
Highway Consumption (L/100km)	0
Average Consumption (L/100km)	0
City Speed (km/h)	30
Highway Speed (km/h)	90
Average Speed (km/h)	60
Correction Coefficient	1
Fuel Consumption On Idling (L/h)	1
Higher Speeds Add (%)	20
Highway Consumption Every (km/h)	50

Figure 19 GNSS Fuel Counter configuration parameters

4. Fuel consumption on idling is used to calculate fuel consumption when ignition is on, but vehicle speed is 0 km/h. By default it is 1 l/h, min 0 and max 5 l/h. Almost in all diesel cars this parameter is less than 1.0 l/h. In gasoline cars this parameter is about 1.5 – 2.0 l/h.

## 5.9 Accelerometer features settings

This window holds the settings which are highly related to accelerometer functionality.

<ul style="list-style-type: none"> <li>Status</li> <li>Security</li> <li>System</li> <li>GPRS</li> <li>Data Acquisition</li> <li>SMS \ Call Settings</li> <li>GSM Operators</li> <li>Features</li> <li><b>Accelerometer Features</b></li> <li>Auto Geofence</li> <li>Manual Geofence</li> <li>Trip \ Odometer</li> <li>Blue-tooth</li> <li>Blue-tooth 4.0</li> <li>I/O</li> <li>OBD II</li> </ul>	<b>Excessive Idling</b> Scenario Settings Disable Low Priority High Priority Panic Priority Eventual Records Disable Enable Time To Stopped (s) 300 Time To Moving (s) 5 Send SMS To SMS Text Idling Event Unplug Detection Scenario Settings Disable Low Priority High Priority Panic Priority Eventual Records Disable Enable Unplug Detection Mode Simple Advanced Send SMS To SMS Text Unplug	<b>Towing Detection</b> Scenario Settings Disable Low Priority High Priority Panic Priority Eventual Records Disable Enable Activation Timeout (min) 5 Event Timeout (s) 0 Threshold (g) 0.22 Angle (deg) 1 Duration (ms) 1000 Make Call To Send SMS To SMS Text Towing	<b>Crash Detection</b> Scenario Settings Disable Low Priority High Priority Panic Priority Duration (ms) 25 Threshold (mg) 1500 Send SMS To SMS Text Crash Crash Trace Disable Enable
---	--	--	--

**Figure 20 Accelerometer features configuration parameters**

### 5.9.1 Excessive Idling

Scenario is activated, when vehicle stops for specific amount of time. You can configure time it takes to turn on this scenario (Time to Stopped). Scenario is activated until vehicle starts moving and keeps moving for amount of time that is configured. You can configure time it takes to turn OFF this scenario (Time to Stopped).

### 5.9.2 Towing Detection

FMT100 activates towing function when these conditions are met:

- Ignition (configured Ignition Source) is OFF
- Activation Timeout (set in Towing detection features) is reached

When Activation Timeout is reached and Ignition is still in OFF state, FMT100 monitors accelerometer data. If Acceleration or Angle value reaches configured threshold for configured Duration (in ms), check Ignition state. If Ignition is still OFF during configured "Ignition check after Event Timeout" time, then event is generated. If configured - sends SMS event message or makes a call. Function will be reactivated after FMT100 again detects change of Ignition state from ON to OFF.

**Towing Detection**

Scenario Settings

Disable	Low Priority
High Priority	Panic Priority

Eventual Records

Disable	Enable
---------	--------

Activation Timeout (min)

Event Timeout (s)

Threshold (g)

Angle (deg)

Duration (ms)

Make Call To

Send SMS To

SMS Text

**Figure 21 Towing detection parameters**

Activation timeout – Activation timeout is time after which FMT100 turns ON Towing detection function if other requirement is met (Ignition OFF state detected). It is measured in minutes.

Ignition check after event – defines time period (in seconds) to check ignition state when Acceleration or Angle value reach. If towing event is generated during this time period, it is skipped. It allows to filter out redundant towing events while entering the car.

Make Call to – if function enabled makes call to specified phone number (configured in pre defined numbers)

Acceleration, Angle – values used to detect towing when ignition is OFF

Duration – defines time period to check Acceleration, Angle values.

### 5.9.3 Crash Detection

Crash Detection functionality can be set according to these settings:

- Threshold (mg);
- Duration (ms).

If accident happens and FMT100 detects acceleration value higher than set threshold value.

During set time period, then device will generate an event. Threshold and duration values are set depending of accident power which you want to detect. FMT100 can detect a slight tapping on the device (Threshold = 100 mg, Duration = 1 ms) or can detect severe accident (Threshold = 4000 mg, Duration = 5 ms).

**Table 8 Crash event values:**

Crash Event element ID	Value, meaning
247	1 – Crash detected. Eventual record.
	2 – Trace changes and device is not calibrated.
	3 – Trace changes and device is calibrated.
	4 – Trace is full and device is not calibrated.
	5 – Trace is full and device is calibrated.

**Crash Trace operation**

Depending on configuration crash record structure follows codec 8 or codec 8 extended protocol structure. If codec 8 extended enabled crash event records are sent without any IO elements, only GNSS and accelerometer data if it is in configured range.

**Table 9 Crash trace accelerometer data structure:**

String IO elements count	String IO element ID	Length	Data
2 Bytes	2 Bytes	2 Bytes	Length Bytes

New IO element is introduced with FMT100 – crash accelerometer data. New IO element ID is 0x101. It stores data from x, y and z axes. Crash accelerometer data structure is shown below. Data being sent is integer 16 type and values are in mG.

**Table 10 Crash trace accelerometer data structure:**

x axis	y axis	z axis
2 Bytes	2 Bytes	2 Bytes

There are two configurable crash trace options: Accel duration (s) and GNSS duration (s). They correspond to the time of accelerometer and GNSS data monitoring before and after aa Crash Event.

**5.9.4 Unplug Detection**

Eventual event will be generated when FMT100 is unplugged from OBD socket.

**Unplug Detection**

Scenario Settings

Disable	Low Priority
High Priority	Panic Priority

Eventual Records

Disable	Enable
---------	--------

Unplug Detection Mode

Simple	Advanced
--------	----------

Send SMS To

SMS Text

**Figure 22 Unplug Detection parameters**

### 5.10 Auto Geofence settings

Auto Geofence – the last known position after movement = off. If your car's being taken away – you can be notified. The shape and size of the geofence zones are parameters. It is possibility to state whether entering in or out of the geofence triggers an asynchronous message.

Auto Geofence option can be configured by following parameters visible in Figure 23 below.

Activation TMO – Time period before Geofence is activated after vehicle stops.

Deactivate By:

- Ignition – If ignition becomes high it will disable Auto Geofence Zone;
- Power Voltage – if power voltage enters entered value it will disable Auto Geofence Zone.
- Digital input 1 – if digital input is triggered it will disable Auto Geofence Zone.
- Feature – Priority of generated event, which will be applied to saved record.
- Enter Event – Event generation on Geofence entrance.
- Exit Event – Event generation on Geofence exit.
- On Both - Event generation on Geofence entrance Or exit
- Eventual Records – Enable or Disable Eventual Records functionality.

Note that Auto Geofencing does not require entering coordinates, instead it requires GPS visibility. If vehicle stopped and activation timeout has passed, an Auto Geofence will be created around vehicle's last position with set Radius value.




Figure 23 Auto Geofence configuration window

### 5.11 Manual Geofence settings

Manual Geofence enables the user to configure certain actions when the vehicle enters/leaves any specific point. It is configurable by coordinates or user can select Geozones on a map.




Figure 24 Manual Geofence configuration window

### 5.12 Trip \ Odometer settings

Trip scenario offers user to configure Trip feature.

Start Speed – GPS speed has to be greater than the specified Start Speed in order to detect Trip Start.

Ignition Off Timeout – timeout to wait if ignition was off, to detect Trip stop.

Continuous distance counting – Not or Continuous can be chosen. For this feature I/O Odometer must be enabled.

If I/O Odometer is enabled and Continuous distance counting variable (Mode) is set to Continuous, **Trip distance** is going to be counted continuously (**from Trip start to Trip stop**). This value is written to I/O Odometer value field. When Trip is over and next Trip begins, Odometer value is reset to zero. When the next trip starts counting continuously starts from the beginning again.




Figure 25 Trip \ Odometer settings

If I/O Odometer is enabled and Continuous Distance Counting variable (Mode) is set “Between Records”, then the distance is going to be counted only between every record made. This value is written to I/O Odometer value field and reset to zero every new record until Trip stops. If later all Odometer values are summed up manually, the user gets the distance driven during the whole period of the Trip.

Advanced Trip Settings have an Eco Score Allowed Events which regulates the amount Eco Score events allowed.

Odometer calculates the distance travelled. Here user is able to select the source of calculations and set a starting value.




Figure 26 Trip continuous distance counting parameter example

### 5.13 Blue-tooth settings




Figure 27 Blue-tooth settings window




Figure 28 General Blue-tooth settings

BT Radio determines state determines Blue-tooth status, possible values:

- a) Disable – Blue-tooth is off;
- b) Enable (hidden) – Blue-tooth is on, device automatically connects to defined MAC, but is invisible for external devices which want to pair with it.
- c) Enable (visible) – Blue-tooth is on and visible for external devices.

Local name can be set according to your needs. If this field is empty, name will be automatically generated:

FMT100xx\_<imei last chars>


Local PIN - PIN code which will be used when external device will try to pair with FMT100.

**NOTE: FMT100 supports ONE connection at a time.**

Security mode possible options:



- a) PIN only – only pin is used when external device tries to connect to FMT100.
- b) PIN+MAC list – PIN is used, also external device’s MAC address needs to be in Authorized MAC list
- c) MAC list only – connection to FMT100 is possible only if external device MAC is in Authorized MAC list.
- d) None – no security enabled.



**Auto Connect To External Device**

Connection Mode

None	Data Link
------	-----------


External MAC

External Name

External PIN

Figure 29 Auto connection to external devices

Here you can enter details of external Blue-tooth headset for hands free communication.  
 External MAC – MAC of your Blue-tooth headset.  
 External Name – Blue-tooth name of you



**Authorized Devices MAC List**

1
2
3
4
5

Import CSV

Export CSV

Figure 30 MAC list

Figure 32 shows list of Authorized MAC addresses which are allowed to connect to FMT100. If list is empty, any external device can connect to FMT100.  
 Blue-tooth Control section shows Discovered Devices and Paired Devices lists.

### 5.13.1 How to connect Blue-tooth Hands Free adapter to FMT100 device

#### Blue-tooth settings configuration

These are instructions how to easily prepare Blue-tooth Hands Free device connection to FMT100 device. First we need to configure FMT100 device Blue-tooth settings for proper connection to this hands-free unit. These are required steps:

**General**

BT Radio

Disable	Enable (hidden)
<b>Enable (visible)</b>	

Local Name

Local PIN

Security Mode

<b>PIN only</b>	PIN + MAC list
MAC list only	None

**Figure 31 Blue-tooth settings**

1. When device configuration is loaded press „**Blue-tooth**“ settings.
2. Turn on BT Radio by pressing „**Enable (visible)**“. You could leave “**Local name**” box empty (then device name will automatically be “FMT100xx\_[last 7 IMEI digits]”) or type your own desirable name.
3. Set Security Mode to “**PIN only**” or “**None**”. You could select “**PIN + MAC list**” or “**MAC list only**” security mode but in this case you need to type external device MAC address in “**Authorized Devices MAC List**”.
4. Set connection mode to “**Data Link**”.
5. Set „**External Name**“ as your Hands Free device name for proper device identification and connection to it. In this example Hands Free headset name is „jabra“ but at least 2 characters are needed to recognize it and connect to it. For better and faster adapter identification in network you could enter a full device name. You could check your Hands Free adapter Blue-tooth name by scanning nearby Blue-tooth devices using mobile phone or computer with Blue-tooth adapter.

**Auto Connect To External Device**

Connection Mode

None	<b>Data Link</b>
------	------------------

External MAC

External Name

External PIN

**Figure 32 Auto Connect settings**

6. Go to “**SMS \ Call Settings**” in left menu and set “**Incomming Call Action**” to “**Do Nothing**” visible at Figure 35.




Figure 33 Incoming Call Action settings

7. After all these steps press „**Save to device**“ to save configuration.
8. Now you can disconnect FMT100 device from a PC or stay connected if you want to make further changes to configuration.

### Connecting Blue-tooth Hands Free adapter

After this configuration you could connect your Hands Free device to FMT100 device. Turn on Hands Free device then turn on its Blue-tooth connection for pairing following your model instructions<sup>4</sup>. Hands Free adapter should make a special sound in ear from speaker or its led identification should change to inform about successful connection<sup>5</sup>. To check if adapter is successfully connected, call to FMT100 device, Hands Free device should start ringing. If you later restart FMT100 device it will automatically connect to this adapter.

#### 5.13.2 Device’s log using your mobile phone.

When FMT100 device starts, automatically Blue-tooth is ON too. Turn on Blue-tooth on your phone. Scan for nearby devices, find your device in list, distinguish device by last IMEI numbers on device module. Press pair, wait until device asks to enter pairing password, type: PIN (default PIN is 5555). Paired device will show up in Paired Devices list. From play/app store download a Blue-tooth terminal (e. g. BlueTerm). Run the app, click find and connect to your device. Now we need to send command to FMT100 through Blue-tooth terminal, type: .log:1

Device will respond Debug enabled and FMT100 log will show up. Do not forget to start save log file to mobile phone.

In order to pair FMT100 device with Android smartphone, make sure that BT radio is enabled (visible) in device configuration. It can be checked via SMS command too:

**getparam 800**

The answer has to be 2, which means “Enabled and visible”.



**Note:** Unfortunately it is not possible to do the same on iPhone, because there is no native SPP Blue-tooth profile support in iPhone.

<sup>4</sup> Hands Free device Blue-tooth connection pairing instructions depends on specific model.

<sup>5</sup> Hands Free device notification about paired Blue-tooth connection depends on specific model.

### 5.14 Blue-tooth 4.0 settings

FMT100 offers Blue-tooth 4.0 (Blue-tooth Low Energy, also referred as BLE) functionality. User is able to discover nearby BLE devices and their services. Another feature is TZ-BT04/05 sensor support. Sensors provide data about temperature and humidity.




Figure 34 Incoming Call Action settings

### 5.15 I/O & OBD II settings

When none of I/O elements are enabled, AVL packet comes with GNSS information only. After enabling I/O element(s) AVL packet along with GNSS information contains current value(s) of enabled I/O element.

Enabled or disabled field – allows enabling I/O element so it is added to the data packet and is sent to the server. By default all I/O element are disabled and FMT100 records only GNSS coordinates.

Priority (AVL packet priority) all records made by FMT100 are regular. Regular packets are sent as Low priority records. When low priority event is triggered, FMT100 makes additional record with indication that the reason for that was I/O element change.

Table 11 Permanent I/O elements

Permanent I/O elements (are always sent to server if enabled)		
Nr.	Property Name	Description
1	Ignition	Logic: 0 / 1
2	Movement	Logic: 0 / 1
3	Data mode	0 – home on stop, 1 – home on move, 2 – roaming on stop, 3 – roaming on move, 4 – unknown on stop, 5 – unknown on move
4	GSM signal	GSM signal level value in scale 1 – 5
5	Sleep mode	Logic: 0 / 1
6	GNSS Status	States: 0 – short circ., 1 – connected. Parameter defines if GPS antenna is short circuit. All the time value will be sent 1. The only

		condition to get value 0, then antenna is damaged and short circuit.
7	GNSS PDOP	Probability * 10; 0-500
8	GNSS HDOP	Probability * 10; 0-500
9	External Voltage	Voltage: mV, 0 – 30 V
10	Speed	Value in km/h, 0 – xxx km/h
11	GSM Cell ID	GSM base station ID
12	GSM Area Code	Location Area code (LAC), it depends on GSM operator. It provides unique number which assigned to a set of base GSM stations. Max value: 65536
13	Battery Voltage	Shows battery Voltage in mV
14	Battery Current	Shows battery Current in mA
15	Active GSM operator	Currently used GSM Operator code
16	Trip odometer	Distance between two records: m
17	Total odometer	Total odometer count: m
18	Digital Input 1	Logic: 0 / 1
19	Fuel Used GPS	Fuel used (ml) by GPS
20	Fuel Rate GPS	Fuel Consumption by average speed (l/100km)
21	Axis X	Accelerometer axis x value
22	Axis Y	Accelerometer axis y value
23	Axis Z	Accelerometer axis z value
24	ICCID	SIM card identification number
25	Eco Score	Eco Score evaluation
26	User ID	User ID for eco score app
27	Network Type	Current active network type
<b>OBD II Parameters</b>		
28	Number Of DTC	Diagnostic Trouble Codes
29	Engine Load	Engine load percentage
30	Coolant Temperature	Engine coolant temperature, °C
31	Short Fuel Trim	Change in fuel level over short time
32	Fuel Pressure	Fuel pressure in tank
33	Intake MAP	Intake manifold absolute pressure
34	Engine RPM	Engine rotations per minute
35	Vehicle speed	Vehicle speed
36	Timing advance	Ignition timing advance
37	Intake air temperature	Intake air temperature
38	MAF	Mass air-flow meter data
39	Throttle position	Throttle position percentage
40	Run time since engine start	Run time since engine start
41	Distance travelled MIL on	Distance travelled with “Malfunction Indicator Lamp” on.
42	Relative fuel rail pressure	Fuel Rail Pressure (relative to manifold vacuum)
43	Direct fuel rail pressure	Fuel Rail Gauge Pressure (diesel, or gasoline direct injection)

44	Commanded EGR	Commanded Exhaust gas recirculation data
45	EGR error	Exhaust gas recirculation error data
46	Fuel level	Fuel Tank Level Input
47	Distance travelled since codes clear	Distance travelled since error codes clear
48	Barometric pressure	Absolute Barometric Pressure
49	Control module voltage	Control module voltage
50	Absolute load value	Absolute load value data
51	Ambient air temperature	Ambient air temperature data
52	Absolute fuel rail pressure	Absolute fuel rail pressure
53	Hybrid battery pack remaining life	Calculated remaining life of a battery pack in hybrid vehicles
54	Engine oil temperature	Engine oil temperature
55	Fuel injection timing	Fuel injection timing
56	Fuel rate	Engine fuel consumption rate

\*- make sure your vehicle supports OBD communication and related OBD codes.



There are two types of operations with Permanent I/O elements: simple monitoring and event generating. Monitoring method is used when current I/O information needed with regular GNSS coordinates. Event generating method is used when additional AVL packet is needed when current value of I/O exceeds predefined High and Low levels. I/O settings allow defining I/O event criteria.

## 5.16 OBD functionality description

### 5.16.1 Supported OBD protocols

1. SAE J1850 PWM (41.6 kbaud);
2. SAE J1850 VPW (10.4 kbaud);
3. ISO 9141-2 (5 baud init, 10.4 kbaud);
4. ISO 14230-4 KWP (5 baud init, 10.4 kbaud);
5. ISO 14230-4 KWP (fast init, 10.4 kbaud);
6. 15765-4 CAN (11 bit ID, 500 kbaud);
7. ISO 15765-4 CAN (29 bit ID, 500 kbaud);
8. ISO 15765-4 CAN (11 bit ID, 250 kbaud);
9. ISO 15765-4 CAN (29 bit ID, 250 kbaud);
10. SAE J1939 CAN (29 bit ID, 250 kbaud).

### 5.16.2 General info

Functionality supports (CAN and K-LINE FAST) protocol, standard pid readout.

### 5.16.3 Initialization

Functionality initializes automatically, finds proper protocol and communicates using it.

#### 5.16.4 Data

Data is saved as I/O elements. OBD I/O elements must be enabled by configurator. All OBD elements are configured in same logic as other I/O property elements.

## 6 SMS COMMAND LIST

### 6.1 Basic commands

Commands are case sensitive. While FMT100 operates in Sleep mode and user tries to send SMS message it will arrive to FMT100 device, because GSM module is enabled.

**Table 12 SMS commands list**

Command	Description	Response
getinfo	Returns RTC time, GPS status, SAT	Yes
getver	Returns code version, device IMEI, modem app version, RTC time	Yes
getstatus	Returns Data Link:0 GPRS:0 Phone:0 SIM:0 OP:24602 Signal:5 NewSMS:0 Roaming:0 SMSFull:0 LAC:0 Cell ID: 0	Yes
getgps	Returns GPS status, Satellite number, Latitude, Longitude, Altitude, Speed, Date, Time	Yes
ggps	Returns location information with Google maps link	Yes
readio	Returns IO status	Yes
cpureset	Resets device	No
getparam	Returns selected parameter value	Yes
setparam	Sets selected parameter value	Yes
flush	Redirects device to other server	Yes
countrecs	Returns record number	Yes
setdigout X,Y	Set digital output X – 0 or 1 (0 – OFF or 1 – ON) Y – timeout value if needed (in seconds)	Yes
fc_reset	Resets fuel consumption parameters	Yes
towingreact	Towing reactivation	Yes
btgetlist	Returns requested Blue-tooth list (values: 0, 1, 2)	Yes
btgscan	Starts Blue-tooth scan (values: none, 1)	Yes
btvisible	Sets Blue-tooth to visible with TMO	Yes
btrelease	Disconnects from current device and pauses auto connect functionality for TMO	Yes
btunpair	Unpair Blue-tooth device	Yes
faultcodes	Fault codes reading from OBD	Yes
obdinfo	Returns OBD info. Protocol, VIN, AdaptiveTiming value, requested PID counter, OBD application state, available vehicle PIDs, mil status, number of DTCs	Yes
cleardtc	Clears a dtc counter and deletes fault codes	Yes

“setparam” and “setdigout” SMS is used to configure device.

Parameter ID consists of 3 or 5 digits. Detailed list of parameters and IDs can be found in chapter number 5.2 “System parameters”

Example: “**username password setparam 102:0**” will disable sleep mode.

Multiple value setting in one sms:

Example: “**username password setparam 2001:wap;2002:user;2003:pass**” will change configured APN name, APN username and APN password. SMS command of limited to 160 characters.

Example: “**username password setdigout 1 60**” will set digital output ON for 60s.

#### 6.1.1.1 getinfo

Response details	Description
RTC	RTC Time
GPS	GPS receiver state. 0 – OFF, 1 – restarting, 2 – ON but no fix, 3 –ON and operational, 4 – sleep mode
SAT	Average satellites

Example: *RTC:2017/1/9 14:13 GPS:1 SAT:0*

#### 6.1.1.2 getver

Response details	Description
App Ver	Firmware version
Modem Ver	Version of modem application
GPS Ver	Version of GPS module
Hw Ver	Version of hardware
Device IMEI	IMEI

Example: *App Ver:01.00.17 Rev:01 Modem Ver:TM25Q\_D\_01.00.00.00\_010 GPS Ver:AXN\_3.82\_3333\_1Hw Ver:FMT1000\_MOD2\_A0:B0:C1:D0 Device IMEI:352094080000950*

#### 6.1.1.3 getstatus

Response details	Description
Data Link	Indicate module connection to server at the moment: 0 – Not connected, 1 – connected
GPRS	Indicate if GPRS is available at the moment
Phone	Voice Call status: 0 – ready, 1 – unavailable, 2 – unknown, 3 –ringing, 4 – call in progress, 5 – asleep
SIM	SIM Status: 0-ready, 1-pin, 2-puk, 3-pin2, 4-puk2
OP	Connected to GSM Operator: numerical id of operator
Signal	GSM Signal Quality [0-5]
NewSMS	Indicate if new message received
Roaming	0 – Home Network, 1 – roaming
SMSFull	SMS storage is full? 0 – ok, 1 – SMS storage full
LAC	GSM Tower Location Area Code
Cell ID	GSM Tower Cell ID Code

Example: *Data Link: 0 GPRS: 1 Phone: 0 SIM: 0 OP: 24602 Signal: 5 NewSMS: 0 Roaming: 0 SMSFull: 0 LAC: 1 Cell ID: 3055*



#### 6.1.1.4 getgps

Response details	Description
GPS	Indicates valid (1) or invalid (0) Gps data
Sat	Count of currently available satellites
Lat	Latitude (Last good Latitude)
Long	Longitude (Last good Longitude)
Alt	Altitude
Speed	Ground speed, km/h
Dir	Ground direction, degrees
Date	Current date
Time	Current GMT time

*Example: GPS:1 Sat:0 Lat:54.666042 Long:25.225031 Alt:0 Speed:0 Dir:0 Date: 17/1/9 Time: 12:52:30*

#### 6.1.1.5 ggps

Response details	Description
D	Date
T	Time
S	Actual Speed
C	Latitude (Last good Latitude), Longitude (Last good Longitude)
Url	Google Maps Link

*Example: D:17/1/9 T:12:52:30 S:0.00 C:54.666042, 25.225032 Url: <http://maps.google.com/?q=54.666042,25.225032&om=1speed:0>*

#### 6.1.1.6 readio #

Response details	Description
ID	I/O element ID
Value	I/O Element value

*Example: Param ID:3 Value:0*

#### 6.1.1.7 getparam

Read parameter value. ID consists of 3 or 4 digits. Detailed list of parameters and IDs can be found in chapter number 8 "Parameter List"

*Example: "getparam 2001" command will request APN name*

*Answer: Param ID:2001 Value:wap*

#### 6.1.1.8 setparam

Sets new value for parameter. ID consists of 3 or 4 digits. Detailed list of parameters and IDs can be found in chapter number 8 "Parameter List"

*Example: "setparam 2001:wap2" will change configured APN name*

*Answer: Param ID:2001 Value:wap2*

*flush #,#,#,#,#,#*

Initiates all data sending by GPRS to specified target server. Comma separated parameters go as numbered:

1. # - IMEI

- 2. # - APN
- 3. # - GPRS LOGIN
- 4. # - GPRS PASSWORD
- 5. # - IP
- 6. # - PORT
- 7. # - MODE (0-TCP/1-UDP)

Parameters are separated by comma (no spaces needed). In case you don't need to enter parameter (Login/Pass) – do not put space, simply put comma and write next parameter.

*Example: opa opa flush 353976012555151,banga,,212.47.99.62,12050,0*

Response details	Description
FLUSH SMS Accepted	FLUSH SMS Accepted
# records found on FLASH	Number of records found on FLASH
Minimum Records to Send: #	Number of minimum saved records to send
GPRS Enabled: #	State of the GPRS connection, 0 – disabled; 1 – enabled
Time Sync: #	Indicates time synchronization on the device, 0 – not synchronized; 1 – synchronized

*Example: FLUSH SMS Accepted. 11 records found on FLASH. Minimum Records to Send: 1. GPRS Enabled: 1. Time Sync: 1.*

#### 6.1.1.9 setdigout

Sets digital output to ON or OFF state (timeout for output is controllable)

*Example: "setdigout 1 60" will set OUT to high level for 60 seconds,  
"setdigout 1" will set OUT to high level for infinite time.*

#### 6.1.1.10 countrecs

Returns the number of records saved in the memory.

#### 6.1.1.11 towingreact

Reactivates Towing Detection to initial state (does not wait for ignition to be OFF). Useful when generated false Towing event and needs reactivation.

#### 6.1.1.12 faultcodes

Response details	Description
LIST	Returns list of fault codes; response when no faults: "No fault codes detected."

*Example: "P0100,P0200,P0300,C0300,B0200,U0100".*

### 6.1.1.13 obdinfo

Response details	Description
LIST of OBD info	Protocol, VIN, Adaptive Timing value, requested PID counter, OBD application state, available vehicle PIDs, mil status, number of DTCs

*Example:* Protocol:5,VIN:N/A,TM:5,CNT:5,ST:OBDDATA  
REQUESTING,P1:0x0,P2:0x0,P3:0x0,P4:0x0,MIL:0,DTC:0,IDO

### 6.1.1.14 btgetlist

btgetlist command needs argument what list should be printed!

*btgetlist 0;* device will respond with **BT\_LIST\_Discovered**

*btgetlist 1;* device will respond with all paired devices

*btgetlist 2;* device will respond with connected bluetooth device

Note: Without argument it is always 0 i.e **BT\_LIST\_Discovered**

In FW 01.00.23 btgetlist (without args) will not respond (as unknown command).

### 6.1.1.15 cleardtc

Clears a dtc counter and deletes all fault codes.

## 6.2 System parameters:

### 6.2.1.1 Movement Source (ID=100)

Device can operate and change its working mode according to motion detection source: ignition (value 0), movement sensor (value 1), GPS (value 2)

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	2	-		U8

### 6.2.1.2 Records Saving/Sending Without TS (ID=107)

When this feature is enabled (value = 1), then records can be saved and sent to server without time synchronization.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	1	1		U8

### 6.2.1.3 Led Indication (ID=108)

Sets led indication: 0 – disabled, 1 – enabled

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	1	1		U8

### 6.2.1.4 GNSS Source (ID=109)

This parameter sets Satellite System, available values:

BeiDou only value: 1

GLONASS only value: 2

Galileo only value: 4

Galileo + BeiDou value: 5

Galileo + GLONASS	value: 6
GPS only	value: 8
GPS + BeiDou	value: 9
GPS + GLONASS	value: 10
GPS + Galileo	value: 12
GPS + Galileo + BeiDou	value: 13
GPS + Galileo + GLONASS	value: 14

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	14	-		U8

#### 6.2.1.5 Battery Charge Mode (ID=110)

Sets battery charge mode: 0 – on need, 1 – After ignition ON.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	1	0		U8

#### 6.2.1.6 Static Navigation (ID=106)

When static navigation is enabled, FMT100 filters out GPS jumps, when it is not moving. When it is disabled, it does not make any changes to collected GPS data.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	1	1		U8

#### 6.2.1.7 Static Navigation Settings (ID=112)

Defines static navigation deactivation source. Available values: 1 – Movement, 2 – Ignition, 3 – Movement and Ignition

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
1	3	1		U8

#### 6.2.1.8 Sleep Mode (ID=102)

Device has three sleep modes: sleep, deep sleep and online sleep mode. While sleep is disabled (value 0) module will never enter sleep mode, in sleep mode (value 1) module reduces level of power usage by turning GPS module to sleep, in deep sleep mode (value 2) module turns GPS module to sleep and device is deregistered from network (note, that FMT100 do not receive SMS while in deep sleep). In online sleep (value 3), device behavior is the same as in deep sleep, but GSM module stays on.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	3	-		U8

## 6.2.2 Sleep Timeout (ID=103)

Sleep timeout is time after which FMT100 goes to GPS Sleep, Deep Sleep or Online Deep Sleep modes if other requirements are met. It is measured in minutes.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
1	3000	-		U8

### 6.2.2.1 Ignition Settings (ID=101)

This parameter sets ignition source available values : 1 – Digital Input, 2– Accelerometer, 3 – DIN1 and Accelerometer, 4 – Power voltage, 5 – DIN1 and Power voltage, 6 – Accelerometer and Power Voltage, 7 – DIN1, Accelerometer and Power Voltage, 8 – Engine RPM, 9 – DIN1 and Engine RPM, 10 – Accelerometer and Engine RPM, 11 – DIN1, Accelerometer and Engine RPM, 12 – Power Voltage and Engine RPM, 13 – DIN1, Power Voltage and Engine RPM, 14 – Accelerometer, Power Voltage and Engine RPM, 15 - DIN1, Accelerometer, Power Voltage and Engine RPM.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
1	15	4		U8

### 6.2.2.2 High voltage level (ID=104)

Sets high level of voltage if ignition settings is set to power voltage.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	30000	30000		U8

### 6.2.2.3 Low voltage level (ID=105)

Sets low level of voltage if ignition settings is set to power voltage.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	29999	13000		U8

### 6.2.2.4 Movement start delay (ID=19001)

Sets the delay of movement detection after movement is made.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
1	60	1		U8

### 6.2.2.5 Movement stop delay (ID=19002)

Sets the delay of stop detection when movement is stopped.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
5	300	60		U8

### 6.2.2.6 Time Synchronization (ID=900)

Sets the time synchronization source. 0 – Disable (GPS only), 1 – NITZ+NTP, 2 – NTP, 3 – NITZ.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	3	1		U8

### 6.2.2.7 NTP Resync (ID=901)

Sets NTP resynchronization time.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	24	24		U8

### 6.2.2.8 NTP Server 1 (ID=902)

Sets the IP of the first NTP server.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
-	-	avl1.teltonika.lt		U8

### 6.2.2.9 NTP Server 2 (ID=903)

Sets the IP of the second NTP server.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
-	-	pool.ntp.org		U8

## 6.3 GPRS parameters

### 6.3.1.1 GPRS Context (ID=2000)

Parameter allows or does not allow GPRS usage. If GPRS is not allowed value is 0, if GPRS is allowed value is 1.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	1		APN (ID=2001) APN Username (ID=2002) APN Password (ID=2003)	S8

### 6.3.1.2 APN (ID=2001)

Parameter defines GPRS Access Point Name.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
Empty	32 char string		GPRS Context (ID=2000) APN Username (ID=2002)	S8[32]

			APN Password (ID=2003)	
--	--	--	------------------------	--

#### 6.3.1.3 APN Username (ID=2002)

Parameter defines APN username. In case operator does not use username for login, value should be empty.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
Empty	30 char string		GPRS Context (ID=2000) APN (ID=2001)  APN Password (ID=2003)	S8[30]

#### 6.3.1.4 APN Password (ID=2003)

Parameter defines APN password. In case operator does not use password for login, value should be empty.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
Empty	30 char string		GPRS Context (ID=2000) APN (ID=2001)  APN Username (ID=2002)	S8[30]

#### 6.3.1.5 Domain (ID=2004)

Parameter defines AVL data destination server IP address. Example: 212.47.99.62

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	54 char string		GPRS Context (ID=2000)	S8[16]

#### 6.3.1.6 Target Server Port (ID=2005)

Parameter defines AVL data destination server port number. Example: 12050

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
Empty	65535		GPRS Context (ID=2000)	U16

#### 6.3.1.7 Protocol (ID=2006)

Parameter defines GPRS data transport protocol. Module can use TCP or UDP transport protocol to send data to server. For TCP protocol value is 0, for UDP protocol value is 1.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	1		GPRS Context (ID=2000)	U8

#### 6.3.1.8 Backup Server Mode (ID=2010)

Sets backup server mode: 0 – Disable, 1 – Backup, 2 – Duplicate.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	2		Backup Server Domain (ID=2007) Backup Server Port (ID=2008) Backup Server Protocolo (ID=2009)	S8[30]

#### 6.3.1.9 Backup Server Domain (ID=2008)

Parameter defines backup server IP address. Example: 212.47.99.62

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	54 char string		Backup Server Mode (ID=2010) Backup Server Port (ID=2008) Backup Server Protocolo (ID=2009)	S8[16]

#### 6.3.1.10 Backup Server Port (ID=2008)

Parameter defines AVL data destination server port number. Example: 12050

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
Empty	65535		Backup Server Domain (ID=2007) Backup Server Mode (ID=2010) Backup Server Protocolo (ID=2009)	U16

#### 6.3.1.11 Protocol (ID=2009)

Parameter defines GPRS data transport protocol. Module can use TCP or UDP transport protocol to send data to server. For TCP protocol value is 0, for UDP protocol value is 1.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	65535		Backup Server Domain (ID=2007) Backup Server Port (ID=2008) Backup Server Mode (ID=2010)	U8

#### 6.3.1.12 Open Link Timeout (ID=1000)

Defines for how many seconds device will keep connection to the server after successful data transfer while waiting for a new record.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
30	259200			U32

#### 6.3.1.13 Response Timeout (ID=1001)

Defines time period in seconds for server response to send records.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
5	300			U32



#### 6.3.1.14 Sort By (ID=1002)

Record sorting parameter is responsible for record sorting order. Value of 0 arranging data starting from newest, while value of 1 arranging data starting from oldest.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	1			U8



ATTENTION! Some GSM operators may disconnect the device from an active data link if the device doesn't send any data for a very long time, even if active data link timeout is set to maximum value. The amount of time that an operator keeps the link open depends solely on the operator. For example, if active data link timeout is set to maximum, 259200 seconds (72 hours), and the device sends data to server every 86400 seconds (24 hours), the operator might disconnect the link earlier and the device will have to connect to the server anew. This may cost extra, depending on the operator GPRS data charge. It is strongly recommended, when using active data link timeout, that data sending to the server should not be very rare (24 hours or more). If data sending is more frequent, then the operator will not disconnect the device from the server.

#### 6.3.1.15 FOTA WEB Settings: Status (ID=13003)

Defines FOTA Web status: 0 – Disable, 1 – Enable.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	1		Domain (ID=13000) Port (ID=13001) Period (ID=13002)	U8

#### 6.3.1.16 FOTA WEB Settings: Domain (ID=13000)

Sets FOTA Web domain.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
Empty	54 char string		Status (ID=13003) Port (ID=13001) Period (ID=13002)	U32

#### 6.3.1.17 FOTA WEB Settings: Port (ID=13001)

Sets FOTA Web port.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	65535		Status (ID=13003) Domain (ID=13000) Period (ID=13002)	U32

#### 6.3.1.18 FOTA WEB Settings: Period (ID=13002)

Record sorting parameter is responsible for record sorting order. Value of 0 arranging data starting from newest, while value of 1 arranging data starting from oldest.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
30	65535		Status (ID=13003) Domain (ID=13000) Port (ID=13001)	U8

## 6.4 Data Acquisition settings

### 6.4.1 Home Network GSM operator code “On stop” parameters

#### 6.4.1.1 Min Period (ID=10000)

This parameter indicates time interval in seconds in order to acquire new record. If value is 0 it means no records by min period will be saved.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	2592000			U32

#### 6.4.1.2 Min Saved Records (ID=10004)

This parameter defines minimum number of records in one data packet that can be sent to server. It has higher priority than Data Send Period (ID=10005).

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
1	255	1		U8

#### 6.4.1.3 Send Period (ID=10005)

This parameter indicates frequency (time interval in seconds) of sending data to server.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	2592000		Min Saved Records (ID=10004)	U32

### 6.4.2 Home Network GSM operator code “Moving” parameters

#### 6.4.2.1 Min Period (ID=10050)

This parameter indicates time interval in seconds in order to acquire new record. If value is 0 it means no records by min period will be saved.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	2592000		Min Distance (ID=10051) Min Angle (ID=10052)	U32

#### 6.4.2.2 Min Distance (ID=10051)

This parameter indicates distance in meters in order to acquire new record. Record is stored when the distance between previous records is greater than parameters value. If value is 0 it means no records by min distance will be saved.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	65535		Min Period (ID=10050) Min Angle (ID=10052)	U32

#### 6.4.2.3 Min Angle (ID=10052)

This parameter indicates angle in degrees in order to acquire new record. If angle difference between last recorded coordinate and current position is greater than defined value, new record is stored. This parameter is operational, when speed is higher than 10 km/h. If value is 0 it means no records by min angle will be saved.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	180		Min Period (ID=10050) Min Distance (ID=10051)	U16

#### 6.4.2.4 Min Speed delta (ID=10053)

This parameter indicates speed difference in order to acquire new record. If speed difference between last recorded coordinate and current position is greater than defined value, new record is stored. If value is 0 it means no records by min distance will be saved.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	255	10	Min Period (ID=10050) Min Distance (ID=10051) Min Angle (ID=10052)	U16

#### 6.4.2.5 Min Saved Records (ID=10054)

This parameter defines minimum number of records in one data packet that can be sent to server. It has higher priority than Data Send Period (ID=10055).

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
1	255	1	Min Period (ID=10050) Min Distance (ID=10051) Min Angle (ID=10052)	U8

#### 6.4.2.6 Send Period (ID=10055)

This parameter indicates frequency (time interval in seconds) of sending data to server.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	2592000			U32

### 6.4.3 Roaming Network GSM operator code "On stops" parameters

#### 6.4.3.1 Min Period (ID=10100)

This parameter indicates time interval in seconds in order to acquire new record. If value is 0 it means no records by min period will be saved.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	2592000			U32

#### 6.4.3.2 Min Saved Records (ID=10104)

This parameter defines minimum number of records in one data packet that can be sent to server. It has higher priority than Data Send Period (ID=10105).

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
1	255	1		U8

#### 6.4.3.3 Send Period (ID=10105)

This parameter indicates frequency (time interval in seconds) of sending data to server.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	2592000		Min Saved Records (ID=10104)	U32

### 6.4.4 Roaming Network GSM operator code “Moving” parameters

#### 6.4.4.1 Min Period (ID=10150)

This parameter indicates time interval in seconds in order to acquire new record. If value is 0 it means no records by min period will be saved.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	2592000		Min Distance (ID=10151) Min Angle (ID=10152)	U32

#### 6.4.4.2 Min Distance (ID=10151)

This parameter indicates distance in meters in order to acquire new record. Record is stored when the distance between previous records is greater than parameter's value. If value is 0 it means no records by min distance will be saved.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	65535		Min Period (ID=10150) Min Angle (ID=10152)	U32

#### 6.4.4.3 Min Angle (ID=10152)

This parameter indicates angle in degrees in order to acquire new record. If angle difference between last recorded coordinate and current position is greater than defined value, new record is stored. This parameter is operational, when speed is higher than 10km/h. If value is 0 it means no records by min angle will be saved.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	180		Min Period (ID=10150)	U16

#### 6.4.4.4 Min Speed (ID=10153)

This parameter indicates speed difference in order to acquire new record. If speed difference between last recorded coordinate and current position is greater than defined value, new record is stored. If value is 0 it means no records by min distance will be saved.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	255	10	Min Period (ID=10150) Min Distance (ID=10151) Min Angle (ID=10152)	U16

#### 6.4.4.5 Min Saved Records (ID=10154)

This parameter defines minimum number of records in one data packet that can be sent to server. It has higher priority than Data Send Period (ID=10155).

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
1	255	1		U8

#### 6.4.4.6 Send Period (ID=10155)

This parameter indicates frequency (time interval in seconds) of sending data to server.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	2592000		Min Saved Records (ID=10154)	U32

### 6.4.5 Unknown Network GSM operator code "On stop" parameters

#### 6.4.5.1 Min Period (ID=10200)

This parameter indicates time interval in seconds in order to acquire new record. If value is 0 it means no records by min period will be saved.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	2592000	-		U32

#### 6.4.5.2 Min Saved Records (ID=10204)

This parameter defines minimum number of records in one data packet that can be sent to server. It has higher priority than Data Send Period (ID=10205).

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
1	255	1		U8

#### 6.4.5.3 Send Period (ID=10205)

This parameter indicates frequency (time interval in seconds) of sending data to server.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	2592000	-	Min Saved Records (ID=10204)	U32

## 6.4.6 Unknown Network GSM operator code “Moving” parameters

### 6.4.6.1 Min Period (ID=10250)

This parameter indicates time interval in seconds in order to acquire new record. If value is 0 it means no records by min period will be saved.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	2592000		Min Distance (ID=10151) Min Angle (ID=10152)	U32

### 6.4.6.2 Min Distance (ID=10251)

This parameter indicates distance in meters in order to acquire new record. Record is stored when the distance between previous records is greater than parameter's value. If value is 0 it means no records by min distance will be saved.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	65535		Min Angle (ID=10152) Min Period (ID=10150)	U32

### 6.4.6.3 Min Angle (ID=10252)

This parameter indicates angle in degrees in order to acquire new record. If angle difference between last recorded coordinate and current position is greater than defined value, new record is stored. This parameter is operational, when speed is higher than 10km/h. If value is 0 it means no records by min angle will be saved.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	180		Min Period (ID=10150)	U16

### 6.4.6.4 Min Speed (ID=10253)

This parameter indicates speed difference in order to acquire new record. If speed difference between last recorded coordinate and current position is greater than defined value, new record is stored. If value is 0 it means no records by min distance will be saved.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	255	10	Min Period (ID=10150) Min Distance (ID=10151) Min Angle (ID=10152)	U16

### 6.4.6.5 Min Saved Records (ID=10254)

This parameter defines minimum number of records in one data packet that can be sent to server. It has higher priority than Data Send Period (ID=10105).

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type

1	255	1		U8
---	-----	---	--	----

#### 6.4.6.6 Send Period (ID=10255)

This parameter indicates frequency (time interval in seconds) of sending data to server.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	2592000		Min Saved Records (ID=10254)	U32

### 6.5 SMS \ Call Settings parameters

#### 6.5.1.1 Allow SMS Data Sending (ID=3000)

Parameter allows or does not allow sending AVL data using binary SMS. If SMS use is not allowed value is 0 and 1 if SMS use is allowed.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	1			U8

#### 6.5.1.2 Data Send Number (ID=3001)

In this field are written GSM numbers, to which will be sent Data SMS.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
1 digit	16 digits			S8

#### 6.5.1.3 Login (ID=3003)

User login is used to ensure module security. Used in every SMS that is sent to device.

Example: ba321

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
Empty	5 char		Password (ID=3004)	S8[5]

#### 6.5.1.4 Password (ID=3004)

User password is used to ensure module security. Used in every SMS that is sent to device.

Example: ab123

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
Empty	5 char			S8[5]

#### 6.5.1.5 SMS Event Time Zone (ID=3006)

Sets time zone

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
UTC -12:00	UTC+13:00			



### 6.5.1.6 Incoming Call Settings (ID=3005)

Parameter defines action during call: 0 –Do Nothing, 1 – Hang-Up, 2 – Report Position

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	2	0		S8[17]

### 6.5.1.7 Authorized phone numbers (ID=4000-4199)

If at least one number is entered then only those number can send messages to device. Number must be entered without “+” or “00”.

Example: 37060012346

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
1 digit	16 digits			String

### 6.5.1.8 SMS Event Predefined Numbers (ID=6000-6009)

In this field GSM numbers are written, to which will be sent “Event SMS” text message. Number must be entered without “+” or “00”.

Example: 37060012346

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
1 digit	16 digits			String

## 6.6 GSM Operators parameters

### 6.6.1.1 Roaming Operator List (ID=5000-5049)

Parameter defines operator list. According to this list module selects operating profile. First in a list is *Home Operator Code*, then Preferred Roaming Operator Codes are written.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
Empty	7 digits			U32

### 6.6.1.2 Operator Black List (ID=5500-5549)

Defines list of black listed operators.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
Empty	7 digits			U32

## 6.7 Features parameters

### 6.7.1 Green Driving parameters

#### 6.7.1.1 Scenario Settings (ID=11000)

Defines priority of green driving scenario:

0 – Disable, 1 – Low Priority, 2 – High Priority, 3 – Panic Priority.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	3			U8

#### 6.7.1.2 Max Acceleration (ID=11004)

It is max allowed acceleration force which can be reached while accelerating without triggering harsh acceleration event.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0.5	10	2.2		Float

#### 6.7.1.3 Max Braking (ID=11005)

It is max allowed braking force which can be reached while braking without triggering harsh braking event.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0.5	10	2.5		Float

#### 6.7.1.4 Max Cornering (ID=11006)

It is max allowed cornering angle which can be reached while cornering without triggering harsh cornering event.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0.5	10	2.1		Float

#### 6.7.1.5 Source (ID=11007)

Choose Green driving source between GPS and Accelerometer. 0 – GPS, 1 – Accelerometer.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	1	0		U16

#### 6.7.1.6 Green Driving Duration (ID=11008)

Green driving duration parameter: 0 – OFF, 1 – ON.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	1	0		U8

#### 6.7.1.7 SMS Text (ID=8034)

Sets event SMS text.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	32 char string	"Green Driving"		S8[32]

## 6.7.2 Over Speeding parameters

### 6.7.2.1 Scenario (ID=11100)

Defines priority of overspeeding scenario: 0 – Disabled, 1 – Low Priority, 2 – High Priority, 3 – Panic Priority.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	3			U8

### 6.7.2.2 Max Speed (ID=11104)

It is max allowed speed which can be reached. If this value exceeded Over speeding event will occur.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	260			U16

### 6.7.2.3 SMS Text (ID=8032)

Sets event SMS tex.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	32 char string			S8[32]

## 6.8 Jamming paameters

### 6.8.1.1 Scenario Settings (ID=11300)

Scenario settings: 0 – Disable, 1 – Low Priority, 2 – High Priority, 3 – Panic Priority.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	3	0		U8

### 6.8.1.2 Eventual Records (ID=11303)

Disables or enables eventual records. 0 – Disable, 1 – Enable.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	1	1		U8

### 6.8.1.3 Time Until Jamming Event Detection (ID=11305)

Defines a delay of Jamming detection. 0 – Disable, 1 – Enable.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	65535	0		U8

## 6.8.2 GNSS Fuel Counter settings

### 6.8.2.1 City Consumption (L/100km) (ID=11900)

Consumption in the city.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	50	0		Double

### 6.8.2.2 Highway Consumption (L/100km) (ID=11901)

Consumption on highway.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	50	0		Double

### 6.8.2.3 Average Consumption (L/100km) (ID=11902)

Average fuel consumption of the vehicle.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	50	0		Double

### 6.8.2.4 City Speed (km/h) (ID=11903)

Speed in the city.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	250	30		Unit64

### 6.8.2.5 Highway Speed (km/h) (ID=11904)

Speed on the highway.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	250	90		Unit64

### 6.8.2.6 Average Speed (km/h) (ID=11905)

Average speed of the vehicle.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	250	60		Unit64

### 6.8.2.7 Correction Coefficient (ID=11906)

Sets the correction coefficient.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0.01	2	1		Double

### 6.8.2.8 Fuel Consumption On Idling (L/h) (ID=11907)

Sets fuel consumption while vehicle is idling

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	5	1		Double

### 6.8.2.9 Higher Speeds Add (%) (ID=11908)

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	250	20		Unit64

### 6.8.2.10 Highway Consumption Every (km/h) (ID=11909)

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	100	50		Unit64

## 6.9 Accelerometer Features settings

### 6.9.1 Excessive Idling settings

#### 6.9.1.1 Scenario Settings (ID=11200)

Defines priority of Excessive idling scenario: 0 – Disabled, 1 – Low Priority, 2 – High Priority, 3 – Panic Priority.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	3			U8

#### 6.9.1.2 Eventual Records (ID=11203)

Disables (0) or enables (1) eventual records with idling value .

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	1			U16

#### 6.9.1.3 Time To Stopped (s) (ID=11205)

Defines minimum time in seconds of vehicle idling before scenario enables.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	255	5		Float

#### 6.9.1.4 Time To Moving (s) (ID=11206)

Defines minimum time in seconds of vehicle idling before scenario disables.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	255	2		Float

#### 6.9.1.5 SMS Text (ID=8033)

Sets event SMS text.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	32 char string			S8[32]

### 6.9.2 Unplug Detection settings

**Note:** „Unplug Detection“ work just in device with battery.

#### 6.9.2.1 Scenario Settings (ID=11500)

Sets priority of the scenario: 0 – Disable, 1 – Low Priority, 2 – High Priority, 3 – Panic Priority.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	3	0		U64

#### 6.9.2.2 Eventual Records (ID=11501)

If enabled, only eventual records of unplug detection will be sent. 0 – Disable, 1 – Enable.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	1	1		U64

#### 6.9.2.3 Unplug Detection Mode (ID=11502)

Sets Unplug detection mode. 0 – Simple, 1 – Advanced. Simple – unplug detection according to external voltage only. Advanced – unplug detection according to: external voltage OR accelerometer.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	1	0		U64

#### 6.9.2.4 Send SMS To (ID=7067)

Enable/disable SNS event sending. 0 – Disable, 1-10 – SMS will be sent to configured GSM number. (SMS \ Call Settings -> GSM Predefined Numbers list.)

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	10	0		U64

#### 6.9.2.5 SMS Text (ID=8036)

Configure unplug SMS event text here.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	160	“Unplug”		U64

### 6.9.3 Towing Detection

#### 6.9.3.1 Scenario Settings (ID=11600)

Sets priority of the scenario: 0 – Disable, 1 – Low Priority, 2 – High Priority, 3 – Panic Priority.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	3	0		U64

#### 6.9.3.2 Eventual Records (ID=11601)

Sets priority of the scenario: 0 – Disable, 1 – Enable.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	1	0		U8

#### 6.9.3.3 Activation Timeout (min) (ID=11602)

Activation timeout in minutes.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	1	0		U8

#### 6.9.3.4 Event Timeout (s) (ID=11603)

Event timeout in minutes.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	1	0		U8

#### 6.9.3.5 Threshold (g) (ID=11605)

Activation timeout in minutes.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	1	0		U8

#### 6.9.3.6 Angle (deg) (ID=11606)

Towing angle in degrees.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	1	0		U8

#### 6.9.3.7 Duration (ms) (ID=11607)

Towing duration in milliseconds.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	1	0		U8

### 6.9.3.8 SMS Text (ID=8035)

Activation timeout in minutes.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	32 char string	"Towing"		S8[32]

## 6.9.4 Crash Detection

### 6.9.4.1 Scenario Settings (ID=11400)

Sets priority of the scenario: 0 – Disable, 1 – Low Priority, 2 – High Priority, 3 – Panic Priority.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	3	0		U64

### 6.9.4.2 Duration (ms) (ID=11401)

Crash duration in milliseconds.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	2000	5		U64

### 6.9.4.3 Threshold (mg) (ID=11402)

Crash force threshold in mg.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	7900	1500		U64

### 6.9.4.4 Crash Trace (ID=11406)

Crash trace parameter: 0 – OFF, 1 – ON.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	1	0		U64

### 6.9.4.5 SMS Text (ID=8037)

SMS event text.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	32 char string	"Crash"		S8[32]



## 6.10 Auto Geofence settings

### 6.10.1.1 Scenario Settings (ID=20000)

Defines priority of trip scenario: 0 – Disable, 1 – Low Priority, 2 – High Priority, 3 – Panic Priority.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	3	0		U8

### 6.10.1.2 Eventual Records (ID=20002)

Eventual Records: 0 – Disable, 1 – Enable.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	1	0		U8

### 6.10.1.3 Generate Event (ID=20001)

Generate Event: 0 – On Exit, 1 – On Entrance, 2 – On Both.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	1	0		U8

### 6.10.1.4 Activation Timeout (ID=20003)

Parameter represents Auto Geofence activation timeout in seconds.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	65535	60	AutoGeofencing priority (ID=20000)	U16

### 6.10.1.5 Radius (ID=20004)

Parameter represents radius of circle with center device coordinates after activating Auto Geofence feature.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	1000000	100	AutoGeofencing priority (ID=20000) Deactivate by (ID=20005)	U32

### 6.10.1.6 SMS Text (ID=8030)

Defines event SMS Text.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	32 char string	“AutoGeofence”		S8[32]

## 6.11 Trip \ Odometer

### 6.11.1.1 Scenario Settings (ID=11800)

Defines priority of trip scenario: 0 – Disabled, 1 – Low Priority, 2 – High Priority, 3 – Panic Priority.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	3	0		U8

### 6.11.1.2 Eventual Records (ID=11801)

Eventual Records: 0 – Disabled, 1 – Enabled.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	1	0		U8

### 6.11.1.3 Mode (ID=11802)

For this feature I/O Odometer must be enabled. If I/O Odometer is enabled, and mode is set to Continuous (value 0), Trip distance is going to be counted till the end of trip, if between records mode is set, Odometer will count distance only between two records.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	1		Scenario Settings (ID=11800)	U8

### 6.11.1.4 Start Speed (km/h) (ID=11803)

This parameter represents speed, which is detected as minimum speed to indicate Trip Start and generate event.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	255		Scenario Settings (ID=11800)	U8

### 6.11.1.5 Ignition OFF Timeout (s) (ID=11804)

This parameter represents timeout to wait if ignition is off in order to detect Trip Stop and generate event.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	65535		Scenario Settings (ID=11800)	U16

### 6.11.1.6 SMS Text (ID=8031)

Defines event SMS Text.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	32 char string	"Trip"		S8[32]

#### 6.11.1.7 Eco Score Allowed Events (ID=11804)

This parameter represents how many eco score events are allowed.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
-	-			U16

#### 6.11.1.8 Calculation Source (ID=11806)

This parameter represents odometer calculation source: 0 – GNSS, 1 – OBD.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	1			U16

#### 6.11.1.9 Odometer value (km) (ID=11807)

Represents odometer value.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	99999999			U16

### 6.12 Blue-tooth settings

#### 6.12.1.1 BT Radio (ID=800)

Enables or disable Blue-tooth feature. 0 – Disabled, 1 – Enable (hidden), 2 – Enable (visible).

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	2	0		U64

#### 6.12.1.2 Local Name (ID 801)

Parameter defines a visible name of FMT100X device.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0 Symbols	30 Symbols			String

#### 6.12.1.3 Local PIN (ID=802)

Parameter Lets to configure Blue-tooth PIN.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0 Symbols	4 Symbols	5555		String

#### 6.12.1.4 Security Mode (ID=803)

Parameter defines a security mode of FMT100X device. 0 – PIN only, 1 – PIN + MAC list, 2 – MAC list only, 3 – None.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	3	0		U64

#### 6.12.1.5 Connection Mode (ID=807)

Settings for automatic connection: 0 – None, 1 – Data Link.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0	3	0		U64

#### 6.12.1.6 External MAC (ID=804)

Defines external device's MAC, for FMT100 to auto connect to.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0 symbols	12 symbols	0		string

#### 6.12.1.7 External Name (ID=805)

Defines external device's name, for FMT100 to auto connect to.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0 symbols	30 symbols	0		string

#### 6.12.1.8 External PIN (ID=806)

Defines external device's PIN, for FMT100 to auto connect to.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0 symbols	8 symbols	0		string

#### 6.12.1.9 Authorized Devices MAC List (ID=830-834)

Parameter allows to add an authorized devices MAC for connection to FMT100.

Minimum value	Maximum value	Default value	Goes with (depends on) parameters	Value type
0 symbols	12 symbols			String

### 6.13 I/O parameters

I/O properties are additional data sources which are recorded along with usual GPS data.

#### 6.13.1.1 I/O#1 property parameter Ignition (ID=50000)

Parameter defines I/O property value. Possible values: 0 – Disabled; 1 – Low; 2 – High; 3 – Panic.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	3		I/O#1 priority (ID=50000) I/O#1 logic operand (ID=50001) I/O#1 High level (ID=50002) I/O#1 Low level (ID=50003) I/O#1 Event only (ID=50004) I/O#1 averaging length (ID=50005)	S8

#### 6.13.1.2 I/O#1 Logic operand (ID=50001)

Parameter defines eventual record is saved. Possible values: 0 – On Exit; 1 – On Entrance; 2 – Both; 3 – Monitoring; 4 – Hysteris; 5 – On Change; 6 – On Delta Change.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	6	0	I/O#1 priority (ID=50000) I/O#1 logic operand (ID=50001) I/O#1 High level (ID=50002) I/O#1 Low level (ID=50003) I/O#1 Event only (ID=50004) I/O#1 averaging length (ID=50005)	S8

#### 6.13.1.3 I/O#1 High level (ID=50002)

Parameter defines high value of triggered I/O property. This parameter is used to set thresholds for I/O properties to generate events.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
-2147483647	2147483647	1	I/O#1 priority (ID=50000) I/O#1 logic operand (ID=50001) I/O#1 High level (ID=50002) I/O#1 Low level (ID=50003) I/O#1 Event only (ID=50004) I/O#1 averaging length (ID=50005)	S32

#### 6.13.1.4 I/O#1 Low level (ID=50003)

Parameter defines low value of triggered I/O property. This parameter is used to set thresholds for I/O properties to generate events.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
-2147483647	2147483647	0	I/O#1 priority (ID=50000) I/O#1 logic operand (ID=50001) I/O#1 High level (ID=50002) I/O#1 Low level (ID=50003) I/O#1 Event only (ID=50004) I/O#1 averaging length (ID=50005)	S32

#### 6.13.1.5 I/O#1 Event only (ID=50004)

Parameter defines whether element should be sent only when event is generated. Possible values:

- 1 – Yes (parameter ID and value is sent when event is generated);
- 0 – No (parameter ID and value is sent in every record).

Minimal value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	1	0	I/O#1 priority (ID=50000) I/O#1 logic operand (ID=50001) I/O#1 High level (ID=50002) I/O#1 Low level (ID=50003) I/O#1 Event only (ID=50004) I/O#1 averaging length (ID=50005)	S8

#### 6.13.1.6 I/O#1 averaging length (ID=50005)

Parameter defines I/O property sample length to average. If no averaging needed default value is 1.

Minimum value	Maximum value	Recommended value	Goes with (depends on) parameters	Value type
0	2147483647	1	I/O#1 priority (ID=50000) I/O#1 logic operand (ID=50001) I/O#1 High level (ID=50002) I/O#1 Low level (ID=50003) I/O#1 Event only (ID=50004) I/O#1 averaging length (ID=50005)	S32

Other I/O property elements can be configured in same logic. All I/O element parameters are listed in the next table.

### 6.13.2 I/O elements parameters and types.

Parameter ID	Parameter Type	Default value	Value range		Parameter name
			Min	Max	
50000	UInt8	1	0	3	Ignition Priority
50001	UInt8	5	0	6	Ignition Operand
50002	UInt8	0	0	1	Ignition High level
50003	UInt8	0	0	1	Ignition Low level
50004	UInt8	0	0	1	Ignition Event only
50005	UInt16	10	0	65535	Ignition Average
7000	UInt8	0	0	10	Send SMS
8000	String	0	0	160	SMS Text
50010	UInt8	1	0	3	Movement Priority
50011	UInt8	5	0	6	Movement Operand
50012	UInt8	0	0	1	Movement High level
50013	UInt8	0	0	1	Movement Low level
50014	UInt8	0	0	1	Movement Event only

50015	Uint16	1	0	65535	Movement Average
7001	Uint8	0	0	10	Send SMS
8001	String	0	0	160	SMS Text
50020	Uint8	1	0	3	Data Mode Priority
50021	Uint8	5	0	6	Data Mode Operand
50022	Uint8	0	0	5	Data Mode High level
50023	Uint8	0	0	5	Data Mode Low level
50024	Uint8	0	0	1	Data Mode Event only
7002	Uint8	0	0	10	Send SMS
8002	String	0	0	160	SMS Text
50030	Uint8	1	0	3	GSM Signal Priority
50031	Uint8	5	0	6	GSM Signal Operand
50032	Uint8	0	0	5	GSM Signal High level
50033	Uint8	0	0	5	GSM Signal Low level
50034	Uint8	0	0	1	GSM Signal Event only
50035	Uint16	1	0	65535	GSM Signal Average
7003	Uint8	0	0	10	Send SMS
8003	String	0	0	160	SMS Text
50040	Uint8	1	0	3	Deep Sleep Priority
50041	Uint8	3	0	6	Deep Sleep Operand
50042	Uint8	0	0	2	Deep Sleep High level
50043	Uint8	0	0	2	Deep Sleep Low level
50044	Uint8	0	0	1	Deep Sleep Event only
7004	Uint8	0	0	10	Send SMS
8004	String	0	0	160	SMS Text
50050	Uint8	1	0	3	GNSS Status Priority
50051	Uint8	5	0	6	GNSS Status Operand
50052	Uint8	0	0	5	GNSS Status High level
50053	Uint8	0	0	5	GNSS Status Low level
50053	Uint8	0	0	1	GNSS Status Event only
7005	Uint8	0	0	10	Send SMS
8005	String	0	0	160	SMS Text
50060	Uint8	0	0	3	GNSS PDOP Priority
5006	Uint8	3	0	6	GNSS PDOP Operand
5006	Uint16	0	0	1000	GNSS PDOP High level
5006	Uint16	0	0	1000	GNSS PDOP Low level
5006	Uint8	0	0	1	GNSS PDOP Event only
5006	Uint16	10	0	65535	GNSS PDOP Average
7006	Uint8	0	0	10	Send SMS
8006	String	0	0	160	SMS Text
50070	Uint8	1	0	3	GNSS HDOP Priority
50071	Uint8	3	0	6	GNSS HDOP Operand
50072	Uint16	0	0	1000	GNSS HDOP High level
50073	Uint16	0	0	1000	GNSS HDOP Low level
50074	Uint8	0	0	1	GNSS HDOP Event only
50075	Uint16	10	0	65535	GNSS HDOP Average

7007	Uint8	0	0	10	Send SMS
8007	String	0	0	160	SMS Text
50080	Uint8	1	0	3	External Voltage
50081	Uint8	6	0	6	External Voltage
50082	Uint16	1000	0	60000	External Voltage Hight
50083	Uint16	0	0	60000	External Voltage Low
50084	Uint8	0	0	1	External Voltage Event
50085	Uint16	10	0	65535	External Voltage
7008	Uint8	0	0	10	Send SMS
8008	String	0	0	160	SMS Text
50090	Uint8	1	0	3	Speed Priority
50091	Uint8	3	0	6	Speed Operand
50092	Uint16	0	0	300	Speed High level
50093	Uint16	0	0	300	Speed Low level
50094	Uint8	0	0	1	Speed Event only
50095	Uint16	1	0	65535	Speed Average
7009	Uint8	0	0	10	Send SMS
8009	String	0	0	160	SMS Text
50100	Uint8	0	0	3	GSM Cell ID Priority
50101	Uint8	3	0	6	GSM Cell ID Operand
50102	Uint32	0	0	999999	GSM Cell ID High level
50103	Uint32	0	0	999999	GSM Cell ID Low level
50104	Uint8	0	0	1	GSM Cell ID Event only
7010	Uint8	0	0	10	Send SMS
8010	String	0	0	160	SMS Text
50110	Uint8	0	0	3	GSM Area Code Priority
50111	Uint8	3	0	6	GSM Area Code
50112	Uint32	0	0	999999	GSM Area Code Hight
50113	Uint32	0	0	999999	GSM Area Code Low
50114	Uint8	0	0	1	GSM Area Code Event
7011	Uint8	0	0	10	Send SMS
8011	String	0	0	160	SMS Text
50120	Uint8	1	0	3	Battery Voltage Priority
50121	Uint8	3	0	6	Battery Voltage
50122	Uint16	0	0	5000	Battery Voltage Hight
50123	Uint16	0	0	5000	Battery Voltage Low
50124	Uint8	0	0	1	Battery Voltage Event
50125	Uint8	0	0	10	Battery Voltage
7012	Uint8	0	0	10	Send SMS
8012	String	0	0	160	SMS Text
50130	Uint8	1	0	3	Battery Current Priority
50131	Uint8	3	0	6	Battery Current
50132	Uint16	0	0	5000	Battery Current Hight
50133	Uint16	0	0	5000	Battery Current Low
50134	Uint8	0	0	1	Battery Current Event
50135	Uint8	0	0	10	Battery Current
7013	Uint8	0	0	10	Send SMS
8013	String	0	0	160	SMS Text



50140	Uint8	0	0	3	Active GSM Operator Priority
50141	Uint8	5	0	6	Active GSM Operator
50142	Uint32	0	0	999999	Active GSM Operator
50143	Uint32	0	0	999999	Active GSM Operator
50144	Uint8	0	0	1	Active GSM Operator
7014	Uint8	0	0	10	Send SMS
8014	String	0	0	160	SMS Text
50150	Uint8	0	0	3	Trip Odometer Priority
50151	Uint8	3	0	6	Trip Odometer
50152	Uint32	0	0	1000000	Trip Odometer High
50153	Uint32	0	0	1000000	Trip Odometer Low
50154	Uint8	0	0	1	Trip Odometer Event
7015	Uint8	0	0	10	Send SMS
8015	String	0	0	160	SMS Text
50160	Uint8	0	0	3	Total Odometer Priority
50161	Uint8	3	0	6	Total Odometer
50162	Uint32	0	0	10000000	Total Odometer High
50163	Uint32	0	0	10000000	Total Odometer Low
50164	Uint8	0	0	1	Total Odometer Event
7016	Uint8	0	0	10	Send SMS
8016	String	0	0	160	SMS Text
50170	Uint8	0	0	3	Digital Input 1 Priority
50171	Uint8	0	0	6	Digital Input 1 Operand
50172	Uint8	0	0	1	Digital Input 1 High
50173	Uint8	0	0	1	Digital Input 1 Low level
50174	Uint8	0	0	1	Digital Input 1 Event
50175	Uint16	1	0	65535	Digital Input 1 Average
7017	Uint8	0	0	10	Send SMS
8017	String	0	0	160	SMS Text
50180	Uint8	0	0	3	Analog Input 1 Priority
50181	Uint8	6	0	6	Analog Input 1 Operand
50182	Uint16	1000	0	30000	Analog Input 1 High
50183	Uint16	0	0	30000	Analog Input 1 Low
50184	Uint8	0	0	1	Analog Input 1 Event
50185	Uint16	10	0	65535	Analog Input 1 Average
7018	Uint8	0	0	10	Send SMS
8018	String	0	0	160	SMS Text
50190	Uint8	0	0	3	Digital Output 1 Priority
50191	Uint8	0	0	6	Digital Output 1
50192	Uint8	0	0	1	Digital Output 1 High
50193	Uint8	0	0	1	Digital Output 1 Low
50194	Uint8	0	0	1	Digital Output 1 Event
50195	Uint16	1	0	65535	Digital Output 1
7019	Uint8	0	0	10	Send SMS
8019	String	0	0	160	SMS Text
50200	Uint8	0	0	3	Fuel Used GPS Priority

50201	Uint8	3	0	6	Fuel Used GPS Operand
50202	Uint32	0	0	1000000	Fuel Used GPS Hight
50203	Uint32	0	0	1000000	Fuel Used GPS Low
50204	Uint8	0	0	1	Fuel Used GPS Event
50205	Uint16	1	0	65535	Fuel Used GPS Average
7020	Uint8	0	0	10	Send SMS
8020	String	0	0	160	SMS Text
50210	Uint8	0	0	3	Fuel Rate GPS Priority
50211	Uint8	3	0	6	Fuel Rate GPS Operand
50212	Uint32	0	0	1000000	Fuel Rate GPS Hight
50213	Uint32	0	0	1000000	Fuel Rate GPS Low level
50214	Uint8	0	0	1	Fuel Rate GPS Event
50215	Uint16	1	0	65535	Fuel Rate GPS Average
7021	Uint8	0	0	10	Send SMS
8021	String	0	0	160	SMS Text
50220	Uint8	0	0	3	Axis X Priority
50221	Uint8	3	0	6	Axis X Operand
50222	Uint16	0	-8000	8000	Axis X Hight level
50223	Uint16	0	-8000	8000	Axis X Low level
50224	Uint8	0	0	1	Axis X Event only
50225	Uint16	1	0	65535	Axis X Average
7022	Uint8	0	0	10	Send SMS
8022	String	0	0	160	SMS Text
50230	Uint8	0	0	3	Axis Y Priority
50231	Uint8	3	0	6	Axis Y Operand
50232	Uint16	0	-8000	8000	Axis Y Hight level
50233	Uint16	0	-8000	8000	Axis Y Low level
50234	Uint8	0	0	1	Axis Y Event only
50235	Uint16	1	0	65535	Axis Y Average
7023	Uint8	0	0	10	Send SMS
8023	String	0	0	160	SMS Text
50240	Uint8	0	0	3	Axis Z Priority
50241	Uint8	3	0	6	Axis Z Operand
50242	Uint16	0	-8000	8000	Axis Z Hight level
50243	Uint16	0	-8000	8000	Axis Z Low level
50244	Uint8	0	0	1	Axis Z Event only
50245	Uint16	1	0	65535	Axis Z Average
7024	Uint8	0	0	10	Send SMS
8024	String	0	0	160	SMS Text

## 6.14 OBD settings

OBD settings are configurable just as I/O Elements parameters.

### 6.14.1 OBD elements parameters and types

Parameter ID	Parameter Type	Default value	Value range		Parameter name
			Min	Max	
40100	Uint8	0	0	3	Number Of DTC Priority
40101	Uint8	3	0	6	Number Of DTC Operand
40102	Uint8	0	0	255	Number Of DTC High level
40103	Uint8	0	0	255	Number Of DTC Low level
40104	Uint8	0	0	1	Number Of DTC Event only
7038	Uint8	0	0	10	Number Of DTC Send SMS
8038	String	0	0	160	Number Of DTC SMS Text
40110	Uint8	0	0	3	Engine Load Priority
40111	Uint8	3	0	6	Engine Load Operand
40112	Uint8	0	0	100	Engine Load High level
40113	Uint8	0	0	100	Engine Load Low level
40114	Uint8	0	0	1	Engine Load Event only
7039	Uint8	0	0	10	Engine Load Send SMS
8039	String	0	0	160	Engine Load SMS Text
40120	Uint8	0	0	3	Coolant Temperature Priority
40121	Uint8	3	0	6	Coolant Temperature Operand
40122	Int8	0	-40	215	Coolant Temperature e Hight level
40123	Int8	0	-40	215	Coolant Temperature Low level
40124	Uint8	0	0	1	Coolant Temperature Event only
7040	Uint8	0	0	10	Coolant Temperature Send SMS
8040	String	0	0	160	Coolant Temperature SMS Text
40130	Uint8	0	0	3	Short Fuel Trim Priority
40131	Uint8	3	0	6	Short Fuel Trim Operand
40132	Uint8	0	0	255	Short Fuel Trim Hight level
40133	Uint8	0	0	255	Short Fuel Trim Low level
401034	Uint8	0	0	1	Short Fuel Trim Event only
7003	Uint8	0	0	10	Short Fuel Trim Send SMS
8003	String	0	0	160	Short Fuel Trim SMS Text
40140	Uint8	0	0	3	Fuel Pressure Priority
40141	Uint8	3	0	6	Fuel Pressure Operand
40142	Uint16	0	0	765	Fuel Pressure Hight level
40143	Uint16	0	0	765	Fuel Pressure Low level
40144	Uint8	1	0	1	Fuel Pressure Event only
7042	Uint8	0	0	10	Fuel Pressure Send SMS
8042	String	0	0	160	Fuel Pressure SMS Text
40150	Uint8	0	0	3	Intake Map Priority
40151	Uint8	3	0	6	Intake Map Operand
40152	Uint8	0	0	255	Intake Map Hight level
40153	Uint8	0	0	255	Intake Map Low level
40153	Uint8	1	0	1	Intake Map Event only

7043	Uint8	0	0	10	Intake Map Send SMS
8043	String	0	0	160	Intake Map SMS Text
40160	Uint8	0	0	3	Engine RPM Priority
40161	Uint8	3	0	6	Engine RPM Operand
40162	Uint16	0	0	16384	Engine RPM High level
40163	Uint16	0	0	16384	Engine RPM Low level
40164	Uint8	0	0	1	Engine RPM Event only
7044	Uint8	0	0	10	Engine RPM Send SMS
8044	String	0	0	160	Engine RPM SMS Text
40170	Uint8	0	0	3	Vehicle speed Priority
40171	Uint8	3	0	6	Vehicle speed Operand
40172	Uint8	0	0	255	Vehicle speed High level
40173	Uint8	0	0	255	Vehicle speed Low level
40174	Uint8	0	0	1	Vehicle speed Event only
7045	Uint8	0	0	10	Vehicle speed Send SMS
8045	String	0	0	160	Vehicle speed SMS Text
40180	Uint8	0	0	3	Timing advance Priority
40181	Uint8	3	0	6	Timing advance Operand
40182	Int8	0	-64	64	Timing advance High level
40183	Int8	0	-64	64	Timing advance Low level
40184	Uint8	0	0	1	Timing advance Event only
7046	Uint8	0	0	10	Timing advance Send SMS
8046	String	0	0	160	Timing advance SMS Text
40190	Uint8	0	0	3	Intake air temperature Priority
40191	Uint8	3	0	6	Intake air temperature Operand
40192	Int8	0	-40	215	Intake air temperature High level
40193	Int8	0	-40	215	Intake air temperature Low level
40194	Uint8	1	0	1	Intake air temperature Event only
7047	Uint8	0	0	10	Intake air temperature Send SMS
8047	String	0	0	160	Intake air temperature SMS Text
40200	Uint8	0	0	3	MAF Priority
40201	Uint8	3	0	6	MAF Operand
40202	Uint16	0	0	656	MAF High level
40203	Uint16	0	0	656	MAF Low level
40204	Uint8	0	0	1	MAF Event only
7048	Uint8	0	0	10	MAF Send SMS
8048	String	0	0	160	MAF SMS Text
40210	Uint8	0	0	3	Throttle position Priority
40211	Uint8	3	0	6	Throttle position Operand
40212	Uint8	0	0	100	Throttle position High level
40213	Uint8	0	0	100	Throttle position Low level
40214	Uint8	0	0	1	Throttle position Event only
7049	Uint8	0	0	10	Throttle position Send SMS
8049	String	0	0	160	Throttle position SMS Text
40220	Uint8	0	0	3	Run time since engine start Priority
40221	Uint8	3	0	6	Run time since engine start Operand
40222	Uint16	0	0	65535	Run time since engine start High level
40223	Uint16	0	0	65535	Run time since engine start Low level

40224	Uint8	0	0	1	Run time since engine start Event only
7050	Uint8	0	0	10	Run time since engine start Send SMS
8050	String	0	0	160	Run time since engine start SMS Text
40230	Uint8	0	0	3	Distance traveled MIL on Priority
40231	Uint8	3	0	6	Distance traveled MIL on Operand
40232	Uint16	0	0	65535	Distance traveled MIL on Hight level
40233	Uint16	0	0	65535	Distance traveled MIL on Low level
40234	Uint8	0	0	1	Distance traveled MIL on Event only
7051	Uint8	0	0	10	Distance traveled MIL on Send SMS
8051	String	0	0	160	Distance traveled MIL on SMS Text
40240	Uint8	0	0	3	Relative fuel rail pressure Priority
40241	Uint8	5	0	6	Relative fuel rail pressure Operand
40242	Uint16	0	0	5178	Relative fuel rail pressure Hight level
40243	Uint16	0	0	5178	Relative fuel rail pressure Low level
40244	Uint8	0	0	1	Relative fuel rail pressure Event only
7052	Uint8	0	0	10	Relative fuel rail pressure Send SMS
8052	String	0	0	160	Relative fuel rail pressure SMS Text
40250	Uint8	0	0	3	Direct fuel rail pressure Priority
40251	Uint8	3	0	6	Direct fuel rail pressure Operand
40252	Uint16	0	0	656	Direct fuel rail pressure Hight level
40253	Uint16	0	0	656	Direct fuel rail pressure Low level
40254	Uint8	0	0	1	Direct fuel rail pressure Event only
7053	Uint8	0	0	10	Direct fuel rail pressure Send SMS
8053	String	0	0	160	Direct fuel rail pressure SMS Text
40260	Uint8	0	0	3	Commanded EGR Priority
40261	Uint8	3	0	6	Commanded EGR Operand
40262	Uint8	0	0	100	Commanded EGR Hight level
40263	Uint8	0	0	100	Commanded EGR Low level
40264	Uint8	0	0	1	Commanded EGR Event only
7054	Uint8	0	0	10	Commanded EGR Send SMS
8054	String	0	0	160	Commanded EGR SMS Text
40270	Uint8	0	0	3	EGR error Priority
40271	Uint8	3	0	6	EGR error Operand
40272	Int8	0	-100	100	EGR error Hight level
40273	Int8	0	-100	100	EGR error Low level
40274	Uint8	0	0	1	EGR error Event only
7055	Uint8	0	0	10	EGR error Send SMS
8055	String	0	0	160	EGR error SMS Text
40280	Uint8	0	0	3	Fuel level Priority
40281	Uint8	3	0	6	Fuel level Operand
40282	Uint8	0	0	100	Fuel level Hight level
40283	Uint8	0	0	100	Fuel level Low level
40284	Uint8	0	0	1	Fuel level Event only
7056	Uint8	0	0	10	Fuel level Send SMS
8056	String	0	0	160	Fuel level SMS Text
40290	Uint8	0	0	3	Distance traveled since codes clear Priority
40291	Uint8	3	0	6	Distance traveled since codes clear Operand
40292	Uint16	0	0	65535	Distance traveled since codes clear Hight level

40293	Uint16	0	0	65535	Distance traveled since codes clear Low level
40294	Uint8	0	0	1	Distance traveled since codes clear Event only
7057	Uint8	0	0	10	Distance traveled since codes clear Send SMS
8057	String	0	0	160	Distance traveled since codes clear SMS Text
40300	Uint8	0	0	3	Barometric pressure Priority
40301	Uint8	3	0	6	Barometric pressure Operand
40302	Uint8	0	0	255	Barometric pressure High level
40303	Uint8	0	0	255	Barometric pressure Low level
40304	Uint8	0	0	1	Barometric pressure Event only
7058	Uint8	0	0	10	Barometric pressure Send SMS
8058	String	0	0	160	Barometric pressure SMS Text
40310	Uint8	0	0	3	Control module voltage Priority
40311	Uint8	3	0	6	Control module voltage Operand
40312	Uint16	0	0	65535	Control module voltage High level
40313	Uint16	0	0	65535	Control module voltage Low level
40314	Uint8	0	0	1	Control module voltage Event only
7059	Uint8	0	0	10	Control module voltage Send SMS
8059	String	0	0	160	Control module voltage SMS Text
40320	Uint8	0	0	3	Absolute load value Priority
40321	Uint8	3	0	6	Absolute load value Operand
40322	Uint16	0	0	25700	Absolute load value High level
40323	Uint16	0	0	25700	Absolute load value Low level
40324	Uint8	0	0	1	Absolute load value Event only
7060	Uint8	0	0	10	Absolute load value Send SMS
8060	String	0	0	160	Absolute load value SMS Text
40330	Uint8	0	0	3	Ambient air temperature Priority
40331	Uint8	3	0	6	Ambient air temperature Operand
40332	Int8	0	-40	215	Ambient air temperature High level
40333	Int8	0	-40	215	Ambient air temperature Low level
40334	Uint8	0	0	1	Ambient air temperature Event only
7061	Uint8	0	0	10	Ambient air temperature Send SMS
8061	String	0	0	160	Ambient air temperature SMS Text
40340	Uint8	0	0	3	Time run with MIL on Priority
40341	Uint8	3	0	6	Time run with MIL on Operand
40342	Uint16	0	0	65535	Time run with MIL on High level
40343	Uint16	0	0	65535	Time run with MIL on Low level
40344	Uint8	0	0	1	Time run with MIL on Event only
7062	Uint8	0	0	10	Time run with MIL on Send SMS
8062	String	0	0	160	Time run with MIL on SMS Text
40350	Uint8	0	0	3	Time since trouble codes cleared Priority
40351	Uint8	3	0	6	Time since trouble codes cleared Operand
40352	Uint16	0	0	65535	Time since trouble codes cleared High level
40353	Uint16	0	0	65535	Time since trouble codes cleared Low level
40354	Uint8	0	0	1	Time since trouble codes cleared Event only
7063	Uint8	0	0	10	Time since trouble codes cleared Send SMS
8063	String	0	0	160	Time since trouble codes cleared SMS Text

40360	Uint8	0	0	3	Absolute fuel rail pressure Priority
40361	Uint8	3	0	6	Absolute fuel rail pressure Operand
40362	Uint16	0	0	65535	Absolute fuel rail pressure Hight level
40363	Uint16	0	0	65535	Absolute fuel rail pressure Low level
40364	Uint8	0	0	1	Absolute fuel rail pressure Event only
7064	Uint8	0	0	10	Absolute fuel rail pressure Send SMS
8064	String	0	0	160	Absolute fuel rail pressure SMS Text
40370	Uint8	0	0	3	Hybrid battery pack remaining life Priority
40371	Uint8	3	0	6	Hybrid battery pack remaining life Operand
40372	Uint8	0	0	100	Hybrid battery pack remaining life Hight level
40373	Uint8	0	0	100	Hybrid battery pack remaining life Low level
40374	Uint8	0	0	1	Hybrid battery pack remaining life Event only
7065	Uint8	0	0	10	Hybrid battery pack remaining life Send SMS
8065	String	0	0	160	Hybrid battery pack remaining life SMS Text
40380	Uint8	0	0	3	Engine oil temperature Priority
40381	Uint8	3	0	6	Engine oil temperature Operand
40382	Int8	0	-40	210	Engine oil temperature Hight level
40383	Int8	0	-40	210	Engine oil temperature Low level
40384	Uint8	0	0	1	Engine oil temperature Event only
7066	Uint8	0	0	10	Engine oil temperature Send SMS
8066	String	0	0	160	Engine oil temperature SMS Text
40390	Uint8	0	0	3	Fuel injection timing Priority
40391	Uint8	3	0	6	Fuel injection timing Operand
40392	Int16	0	-21000	30200	Fuel injection timing Hight level
40393	Int16	0	-21000	30200	Fuel injection timing Low level
40394	Uint8	0	0	1	Fuel injection timing Event only
7067	Uint8	0	0	10	Fuel injection timing Send SMS
8067	String	0	0	160	Fuel injection timing SMS Text
40400	Uint8	0	0	3	Fuel Rate Priority
40401	Uint8	3	0	6	Fuel Rate Operand
40402	Uint16	0	0	32767	Fuel Rate Hight level
40403	Uint16	0	0	32767	Fuel Rate Low level
40404	Uint8	0	0	1	Fuel Rate Event only
7068	Uint8	0	0	10	Fuel Rate Send SMS
8068	String	0	0	160	Fuel Rate SMS Text

## 7 EC Declaration of Conformity



## CHANGE LOG

Nr.	Date	Version	Comments
1	2018-04-19	0.01	Preliminary draft release.
2	2018-05-14	0.02	Updated Crash Detection, Green Driving functionalities. Added Tracking on Demand functionality. Minor fixes.
3	2018-05-24	0.03	Changed Figure 20.
4	2018-05-29	0.04	Minor fixes. Battery information updated Updated information about codec8 and codec8E
5	2018-08-22	0.05	Minor changes in text.
6	2018-10-16	0.06	Driver download link changed